


Hisense

Namestitev

*/Vzdrževanje
Priročnik*

- NOTRANJA ENOTA TOPLITNE ČRPALKE -

Serija	MODEL
Hi-Therma	AHS-044HCDSAA-23
	AHs-060HCDSAA-23
	AHS-080HCDSAA-23



IMPORTANT:

*PRED UPORABO
KLIMATSKE NAPRAVE S
TOPLOTNO ČRPALKO
PREBERITE IN PREBERITE TA
PRIROČNIK.
SHRANITE TA PRIROČNIK.
ZA PRIHODNJO UPORABO.*

0 2 1Q
IZVIRNA NAVODILA

Declaration of Conformity (+t'čturer+ Declaration)	Déclaration de conformité (Déclaration du fabricant)	OeciamÓn Oe Co m ed (Declaración del Fabricante)	EXchiar di Eatm#A (Chiarazione del produttore)	Konformitätserkl exmg (Zaječe krave)
Declaração de conformidade (declaração do fabricante)	Conformiteitsverklaring (Fabrikanterkla ring)	Deklaracija Zgodnosti (Dekl aracj a wytwórcy)	Uygunluk Beyanı (Öretici Beyanı)	Declarare de cmtormñeTe (OeOerg# producătorului)

Qingdao Hleenee Hitachi Air-conditioning Systems Co., Ltd. .

* dedere a pod l'e aole ia-nons4b|lly lhat lha ecju¥mer l la which lhe deaare6o1 datas

*cn e sea\$eulsreeponaablWiéqw*C*qNpsremtWe8parM senmdBohwafon:

ee dakara bajo su ón@ resposeatglk zd que el egulpo a] qua hara refererica la dactaraÓon:

#@ dichim salto Ta proprio re sol litt cha @i apparecchi a cui 6 rififiTa questa eùgfiiarazione:

8e erld8rt sulseine al@nige Verantwortung dal die Ausfl8bmig far dÀ ñgese Erklärung bemrnrid

■@ declara sob sua exclusiva responsabilidade que os equipamentos a que esta declaração se refere:

e vettodaart hlerblj ag algae exclu varanTwaordafijkJlaô dar da app calur waerag desa' vadda ng balrekktng haft:

o "deldaru@se wtas z] i odpowledzlaTnedC le urzg0zer.In, których @ deldma@ dotyczy;

■@ tamamen kendi sorumluluğunda olmak üzere bu bildirinin ilgili olduğu donanımının aşağıdaki gibi olduğunu beyan eder:

■@ declară pe proprie răspundere că echipamentele la care se referă această declarație:

N e ale m Arty s fodorrifg sfandard(e) ali drugimi normativnimi dommençō), proxtetl theo Pese so usen 'rf aq rdençē mil óur

a aont connor & Taux norma(s) o+i aura(a} documanga) normlga), pour atflard qu'Ms aolent ut!fsg'g oortfçsmârnent â noa /nstzuçTlons! e æ ea&n en confôrmäfad k(s) stguleme(s) narmats) u atroce) dokumenti(s) normaévo(s). z¥arrg+lo que Jean utl4zados de acuerdo con

Bi6 4ONO rasnforrii BI(i) Qi Wnda@g) o e4Iro[i] documento(i} e ñcar8tfeo n0ffl18ovo. a p8tto vel u8et! ifi confixmi6 alt rcelre alrzlsnl:

G 4s dacFdan folgandan Norm(an) zdm alnem ardaren Normdokument Oder -dökumantan entspüch#arrtsprechen, zwar dér Vo¥auasa

u esT8o am confôrriktade ajá) segulne(s) norma(s) ou outro(s) Wufrmntots\$ rerrria8yo(e). deBde que sedes ejem utreaüs de

■@ conform de volgende norm(en) of één of meer andere bindende documenten zijn, op voorwaarde dat ze worden gebruikt ovar prihod g Onza klatrucdas.

ge apelñwymogi nas@pujgých norm Innyeh dd'urrentów normakzacyjnyeh,.pod walam ža usa zgodnle z naazymt nBtzukqarrd

¥ türünün, tal benmrz'a göre Tuh iTrast hopKryle egagidek! BstandBröar ve belirten belgelerle uyumKidor

'i e sunl 7n cenformitete cu u=n6lorui (urtr-stearelel slari4efd(e) ese sir(el wumer-Xej r-xtriatlge), cu condllet ce aceelea ed de ub1bale Tn confornillint- *u Inanma naase:-

EN IEC 55014-1:2021

EN 55014-1:2017+A11:2030 AU:2019 - AZ:2019 * A15:2021

EN IEC 5S014-2:2021

EN 80335-2-40:2003 - A11:2004 * A12-2005 * A1:2006 - AZ:Z009 * A13:Z012

EN IEC 61000-3-11:2010

EN 60335-2-21:2021 * A1:2021

EN 61080-3-12:3011

EN 60335-1:2012 - A11:2014 * A13:2017 * A1:2019 *

EN 55014-1:2017+A11:2030 AU:2019 - AZ:2019 * A15:2021

EN 80335-2-40:2003 - A11:2004 * A12-2005 * A1:2006 - AZ:Z009 * A13:Z012

EN 60335-2-21:2021 * A1:2021

EN 62234:2008

EN 378-2:2016

■@ following the provisions of:
conformgrrent auz atppuhzYorra des.
ali siguiendo los d'spos cione de:
4co secondo Te prese zforii per:
-m gem86 den Vorsotfilnen der:
a @ de acordo com o prówato em!
n ovazeenkomsag ñegalzngteft of: a
n% z posfanow?eniamiDyre
■@ bunun koşullarına uygun olarak:

3o06/4z/ES

2014/30/EU

2014/35/EU

Z01Z/19/EU

2011/65/EU

Z044/517/EU

190t/2006/JEC

2009/125/ES

EU št.

813/2013

2014/68/EU

^^ W Dire+ivea. aa amerdert.

u e Directive; telles que moditiéas.

u m+Directivas, sagún lo enmerdmto.

u e Oiretbve, come de modLsa.

■@ Direktiven, gemäß nderung.

H a-Directiváa. conforme Oliva@o em.

o '-Rchül]neri. zoala genemteerd.

■@ z późniejszymi poprawkami.

■@ Değiştirilmiş halleriyle Yönetmelikler.

".in uog-edpoeJveyby ñ

-œ app ouVé par:

- 03 * y considerado favorablemente por:
- 04 * e valutato positivamente da:
- 05 * und positiv bewertet von:
- 06 * e considerado positivo por:
- 07 * en goedgekeurd door:
- 08 * i pozytywną opinią:
- 09 * ve şu kurum tarafından olumlu olarak değerlendirildiği üzere:
- 10 * și a fost apreciat pozitiv de:

Conformity Assessment Procedure: module A
Category: I

Pressure Equipment Components	Category under 2014/68/EU	Assessment Procedure
Heat Exchanger(plate)	Category I	Module H
Piping pressure accessories	Art.4.3	++

Maximum allowable pressure(high pressure sides) : 4.15MPa

Maximum allowable pressure(low pressure sides) : 2.21MPa

* only AHS-044/060HCDSAA-23

m' @ " Manu scurlng nuróal aña mänútäcturnrig'yes-r. refet ro .Naniäpotá.,.

Had:TfiiB dactără órf üaðónla's trnaha,.I£ iøchnlcal'ót ópor tlonal.mp'difl+çál a'ahalnroôucea stranka ma'nufaciurá#a'co anL

02 * Numéro de fabrication et année de fabrication : se référer à la plaque signalétique du modèle.

Remarqué C.mâ déclaration dey|ént inüalide sl des mòdificatíone.. eiclmigueă'ou opera ñehee"éorit intrpdúiteø sarrs le censënte'wnt:dú ldóricent.

.ø aø " Nürne'ro. de hbricaÓón y aha de:feMcaclön- consulte la play de ktefitifceclón del modelo:

idol..Bhd dec a+ac+ón @a de terier..vafid s.aa Inbod en modéfaciones.tccnicae u operat'vøs.sin:el oonsqntmlqnto dët

"# " Numøio dl þaðb'rIcäzlona'a'annó "dT fâbbflcæJorja: lark rlfaiml'anlõ alia targhiatta ñhód@lõ.

Nó s- gost dlcNarazlo'ne'non G'yallda sø veñgono Tütrodöua rnodi elm 'tecrghå õ o'perajíVa'%nza ll córtsenao "del prôduooie.

" marst ejJung6nmmer wtd Harsællungs]ahí. alðhø Typemcn8a aes Moøe'llo

H' was. bese Er.klaruns v-nlart.Jhre Gúiligh-ii. w-+rn onne Zuscmur's dos Hbars .tech?lsche oóar b-irieblch- Ār-^-rungan vórgqnommen wa'rueñ.

" Númeró da fabrlcaç-go ø an'o de fia tloaçõo- coñ8ulte a gac'a.de.Idan lf+caçžio do.modato...

Hóia- Esla õaða c0ô.to' mlnvalids sa madflfçaçõaa.lii'ah-aa o'u.óperael0nala pena lnldàs 'aâtn ó consintima'nio œ' fÂödcante.

."moo Pábncagengmcœ énlalvi e\$;UeheillypepieaŞeyen ñetmodèL

'õprne-rkEng: Ta yergJartng.is unldlg.sts.techrgécIN.or oparationêla.wplgtngen so ãanggb clñ;sin'r œastœnmlng v déifäbilkant

03 * Numer produkcyny i rok produkcji: patrz tabliczka znamionowa modelu.
Uwagi: Nir ej za deklara'cje traCi wgžrioëi w p'rzypedku widow e'nla zm techfrdczrych lub ploa@cy§N'yç bez zgody producenta.

a œ " tJr6nm nu¥t1ar0e we aæ[i zj yITi: modalni Etkau ¥0 Yaw n.

Nol Uraainrn iYñi Æernadan tekrók veya oflœaayona! dëgi\$fklixfer.yap liraa au oeyen gaçiae olur...:

° Q t Nçimatrl\ de fabrlca]fè. I anus de fëbrica@! c'ónguiel petuion ðe Id8nTlf*cer% a r ð i d e l a i \ü J.

Idc- Ac-aSf8 dëolerfiè ôsvlne nula dàca ã'unt introduûe mç'i1tfirØ/J Tennio9 ski ooere lónale l2ra.éenorô produalðMul.

Hieeneè Itatia S.r.t. (Ad.: Via MontefeoRro BA, 20156 Milšno.)

11 * Is authorised to Compile the Technical Construction File.

12 * est autorisé à constituer le dossier technique de constructions.

13 * está autorizado a compilar el expediente técnico de construcción.

14 * è autorizzato a compilare il fascicolo tecnico della costruzione.

15 * ist berechtigt die Technische Dokumentation zu erstellen.

16 * está autorizada a compilar o arquivo técnico de construção.

17 * is bevoegd om het Technisch Constructie Dossier samen te stellen.

18 * jest upoważniona do opracowania Dokumentacja techniczno-konstrukcyjna.

19 * Teknik Yapı Dosyasını Derlemeye yetkilidir.

Datum: 25. november 2022

Add.: Nö: 218, Öianwangang Road, Economic and Technological Devebptment Zone, .Öingdao, Čhlna

Specificaūor s i \ th s 'i ar ual so subjecl spremeniti wltf uul i4ut'ce da w'at Hisense n uy hrlr g najnovejše -nnuvations \u tile r cuslon.

En0lis' različica '- The original one; other laf guages are irarislaid from English Should anr discfepancy occur med angleško in prevedeno različico6, se angleška različica šteje za nr2vaiT

Français

Les cnraclérstfQues gubliées dans ce maoueT œuvent ê "e modifiées sane préavis, Hisense souhaitant pouvo'r toujours olfrir ù Da stranke iea demiere'6 inovacie.

La version anglaise esl la version orig'nale. Yes autres lanØues som traduïles de l'anglais. En cas de divergence entre les versions anglaise et traduite. la version .angtnise prëvaiudra.

Español

Las especifcactones dc este manual oetän sÚjDt s a cambros sin previo avtso a fin de que Hisen se puede otzecer tas últimas innovaciones a sus clientes.

L 0 version en inglés es la original. y las versiane s en otros id'nmas sun trarlt wiones ale la inglesa. En caso da discrepancies øntre Ta vorsión inglesa y las versione s had tiedas, preval ecerä la versión inglcsa.

Italiano

La \$p-ecifiche di questo n aøu ale song soggorts a m9difica \$enza preavviso afffnchä Hisen\$ha pgşşşa o€rire ai propri clienti le ultime novilä.

La versiope inglese e T'çnginnle e \e versioni in altre linguc sorto tröduztonf dali'inglcse. In caso di divergenze inn \e ersione Inglese e quelle uadotte, fó fede la version+e Inglese.

Deutsch

Bei den techn schen Angaben in diesem Handbuch sind Änderungen vorbehalten. aamit H'sense semen Kunden die jeweiTs neues n inovacije präsenüeren hann.

Oie engiische Fgssung is1 das Onq'nal. und die Fnssungen in anderan Sprrtchen weEen ans dem Engtschen über- seLzt. Solken die engt'sche und d e überseLzlen Fassungen voneinanaer abweichen. so hat die englische Fas ung Vorr9ng.

Português

As especificações apresentadas neste rt anual estño sujeitas a alndiações sem aviso prévio, õe modo a que a Hisense possa oferecer aos seus clien\es. da foona main expedita possivel. as inovações n'aís recentes.

A versão Inglesa é a origina'. as versões em outras lfmuas são tradu zidas do ingl?s. Em caso de divergência entre a versão em lfngua inglesa e as versões traduzidas, faz fê a versão em lingua irtglesa.

Specifikacije v tem priročniku x "nn be gewiiz'gd without further notice, tako da lahko f4:sense zagotavlja 2'jn strankam z nieriwste Innovates

Angleška različica je izvirnik - drugi jeziki so prevedeni iz angleščine V primeru verscl'illen trissen En-gel različica in prevedeni xe's'es, angleški vers'e ima voorfang.

@mtezzczone w niøiø szej insTrukcj i obsfugi dane Lochn czn e rnogą ulec zmianie bez uprzed nfego pow\adomienien ze wzgJediu na nnowacy ne rozwiazania. jakie firrrta Hzsense nieus\artnie wp rowadzą z my9lą o swojih hTiontach.

wersja angielska jest wersja orygzna-nrj - wszystkie pozostałe stanow'e jej ttiumawen'e nB Odgzyki, W przypod ku sfwierdzenta jah chkoiwiek razbieżnoēc m\ dzy çyoinafe+ - i go ttumaczeniem. Rozszygaią-- test wersja w tczyku arigiels k im.

Bu hilavuzduki teknik ózellikler I-4i\$onse'nin müsterilerine en yeni inovasyon lari sunabifmesi için önceden haber verilmenden dağıqt'rilebilir.

İngilizce Büriim orijrial ofanidir ve diger diTlar Ingilizce'den çgvrilmi ti". Ingitzce ve çevrili Bürumler ara6ında farklilik olması durumunda ingilizcə \$ünim esas aliismalidir.

Română

În poçifiraliile rtin acest mlnt a\ po[fi modificate flñrñ no\Jficarú prealabiTû. pentru hisen sepo0tă pt ne la +4ispoZ' i0 clien\ilor nostri -ltimele inova ii

Versi nea origortală este cea 'n limba engTez ü; vcrsi "nilc \n atte limi' s int iradt se din llimD0 Ongležš Oaca exiSt3 vrco rtiscrepan]ě Intro versi mile in iimha engTez a i v0+s'tinea iradi T, prevaleazú vnrsi inca in limba engleză.



Following Regulation EU No. 517/2014 on Certain Fluorinated Greenhouse gases, it is mandatory to fill in the label attached to the unit with the total amount of refrigerant charged on the installation.
Do not vent R32 into the atmosphere; R32 are fluorinated greenhouse gases covered by the Kyoto protocol global warming potential (GWP) R32 = 675. The Tn of CO₂ equivalent of fluorinated greenhouse gases contained is calculated by indicated GWP * Total Charge (in kg) indicated in the product label and divided by 1000.

En fonction de la Réglementation CE N° 517/2014 concernant certains gaz à effet de serre fluorés, il est obligatoire de remplir l'étiquette attachée à l'unité en indiquant la quantité de fluide frigorifique qui a été chargée à l'installation.
Ne laissez pas le R32 se répandre dans l'atmosphère; le R32 sont des gaz à effet de serre fluorés, couverts par le protocole de Kyoto avec un potentiel de réchauffement global (PRG) R32 = 675.
Les Tn d'équivalent-CO₂ de gaz à effet de serre fluorés contenus est calculé par le PRG * Charge Totale (en kg) indiquée dans l'étiquette du produit et divisé par 1,000.

Español

De acuerdo con el reglamento U con la unidad con la cantidad tot No. descargue el R32 en la a (GWP)= 675.
Las Tn de CO₂ equivalente de ga del producto y dividida por 1000.

517/2014 sobre determinados gases fluorados de efecto invernadero con que se ha cargado la instalación.
Iera; R32 son gases fluorados cubiertos por el protocolo de fluorados de efecto invernadero contenidos se calcula por el PCA i

na spletne mestu
lia -la ai

am normativa EC " 517/Z0 4 su d<err "inas .ges rluor+Qaa ai pau serra. à "oblige s rr ilere l'e sull'un#à thura,os.fa

Non scaricare R32 nell'atmosfera; R32 sono gas fluorurati ad effetto serra che in base al protocollo di Kyoto presentano un potenziale riscaldamento globale (GWP) R32 = 675.
Le Tn di CO₂ equivalente di gas fluorurati ad effetto serra contenuti si calcola dal GWP indicato * Carica Totale (in kg) indicato nella etichetta del prodotto e diviso per 1000.

Português

Em conformidade com a Regulamentação da UE Nº 517/2014 sobre determinados gases fluorados com efeito de estufa, é obrigatório preencher a etiqueta fixada na unidade com a quantidade total de refrigerante carregada na instalação.

Tn de CO₂ equivalente de gases fluorados com efeito de estufa é calculado pelo GWP indicado * Carga Total (em kg) indicado no rótulo do produto e dividido

Conform richtlijn EC Nº 517/2014 voor bepaalde fluorbroeikasgassen, dient u de tabel in te vullen op de unit met het totale koelmiddelvolume in de installatie. Laat geen R32 ontsnappen in de atmosfeer; R32 zijn fluorbroeikasgassen die vallen onder het protocol van Kyoto inzake klimaatverandering global warming potential (GWP) R32 = 675.

Tn van CO₂-equivalent van fluorbroeikas gassen wordt berekend door het aangegeven GWP * Totale hoeveelheid (in kg) aangegeven in het product label en

Polski

Zgodnie z Rozporządzeniem U umieszczonej na klimatyzatorze Nie należy uwalmiać czynnika cl potencjalnym wpływie na global W celu obliczenia wyrażonej ró na etykiecie całkowitą masę ga:

2014 w sprawie fluoro ynnika chłodniczego v go R32 do atmosfery: enie (GWP), R32 = 6; iklem CO₂ ilości fluo stalacji (w kg) i uzyskan:

w cieplarnianych, wymagane jest podanie na etykiecie informac jo do obiegu instalacji klimatyzacyjnej. wchodzą uwzględnione w protokole z Kioto fluorowane gazy ci w cieplarnianych (w tonach), mnożymy podaną wartość GWP p ty przez 1000.

Türkçe

Florlu Sera gazlarılarındaki AB Yönetmeliği No. 517/2014 uyarınca üniteye ilişirilmiş etikete kurulumda doldurulan toplam soğutma gazı miktarının yazılıması zorunludur.

R32'yi atmosfere tahliye etmemen: R32, Kyoto protokolü küresel ışınlama potansiyeli (GWP) R32 = 675 kapsamında florlu sera gazlandır. Florlu sera gazlarının CO₂ eşdeğer tonu, ürün etiketinde belirtilen endike GWP.* Toplam Dolum miktarı (kg olarak) çarpımının 1000'e bölünmesiyle:

În conformitate cu Regulamentul UE 517/2014 privind anumite gaze fluorurate cu efect de seră, este obligatorie completarea etichetei atașate la unitate cu cantitatea totală de agent frigorific încărcat în instalare.

Nu evacuați R32 în atmosferă; R32 sunt gaze fluorurate cu efect de seră care cad sub incidența potențialului de încălzire globală al Protocolului de la Kyoto ' R;32 = 675.

Tohajuju agent 'GOL al gaúalrs.guòr+rate.cu èfect d'usér&.oónlinuta se calculaazg prin'rboerea OWP t.C@lizaú.tmalg (in ¥') in

.ih eTichea

WARNING

BURST HAZARD

Do not allow air or any gas mixture containing oxygen into refrigerant cycle (i.e. piping).

RISK OF EXPLOSION

The compressor must be stopped before removing the refrigerant pipes.

All service valves must be fully closed after pumping down operation.

WARNING

This symbol displayed on the unit indicates that this appliance is filled with R32, an odourless flammable refrigerant gas with low burning velocity (A2L class pursuant to ISO 817). If the refrigerant is leaked, there is a possibility of ignition if it enters in contact with an external ignition source.

CAUTION

This symbol displayed on the unit indicates that this appliance shall be handled by authorized service personnel only, referring to the Installation Manual.

CAUTION

This symbol displayed on the unit indicates that there is relevant information included in the Operation Manual and/or Installation Manual.

Français (Seulement en utilisant R32)

AVERTISSEMENT

DANGER D'ÉCLATEMENT

Evitez que de l'air ou un mélange de gaz contenant de l'oxygène ne pénètre dans le cycle frigorifique (c.-à-d. tuyauterie).

RISQUE D'EXPLOSION

Veillez à arrêter le compresseur avant de retirer les tuyauteries frigorifiques.

Veillez à fermer complètement toutes les vannes de service après la vidange.

AVERTISSEMENT

Ce symbole affiché sur l'appareil indique que l'appareil est chargé avec R32, un gaz frigorigène inflammable sans odeur à basse vitesse de combustion (Classe A2L selon ISO 817). En cas de fuite de frigorigène, il existe un risque d'incendie si celui-ci est exposé à une source d'inflammation externe.

ATTENTION

Ce symbole affiché sur l'appareil indique que seul le personnel de maintenance autorisé doit manipuler l'équipement, en se reportant au manuel d'installation.

ATTENTION

Ce symbole affiché sur l'appareil indique que le manuel de fonctionnement et/ou le manuel d'installation contient des informations importantes.

Español (Sólo cuando se utiliza R32)

ADVERTENCIA

RIESGO DE EXPLOSIÓN

Evite la entrada de aire o cualquier mezcla de gases que contenga oxígeno en el ciclo de refrigerante, por ejemplo, en las tuberías.

RIESGO DE EXPLOSIÓN

Antes de retirar las tuberías de refrigerante debe detener el compresor.

Tras recuperar el refrigerante todas las válvulas de servicio deben estar completamente cerradas.

ADVERTENCIA

Este símbolo mostrado en el aparato indica que este está cargado con R32, un gas refrigerante inflamable e inodoro con una velocidad de combustión lenta (Clase A2L de acuerdo con ISO 817). Una fuga de refrigerante puede provocar un incendio si entra en contacto con una fuente de combustión externa.

PRECAUCIÓN

Este símbolo mostrado en el aparato indica que este debe ser manipulado únicamente por personal de un servicio autorizado con el soporte del manual de instalación.

PRECAUCIÓN

Este símbolo mostrado en el aparato indica que los manuales de funcionamiento y/o de instalación contienen información importante.

Italiano (Solo quando si usa R32)

AVVERTENZA

PERICOLO DI SCOPPIO

Fare in modo che all'interno del ciclo di refrigerazione non entrino aria o qualsiasi miscela di gas contenente ossigeno (per es. le tubazioni).

RISCHIO DI ESPLOSIONE

Il compressore deve essere arrestato prima di rimuovere i tubi del refrigerante.

Tutte le valvole di servizio devono essere completamente chiuse dopo lo svuotamento della pompa.

AVVERTENZA

Questo simbolo visualizzato sull'unità indica che l'unità è caricata con R32, un gas refrigerante infiammabile e inodore con una velocità di combustione lenta (Classe A2L secondo ISO 817). Una perdita di refrigerante può provocare un incendio se entra a contatto con una fonte di combustione esterna.

AVVERTENZA

Questo simbolo visualizzato sull'unità indica che l'unità deve essere gestita solo da personale di servizio autorizzato, facendo riferimento al Manuale di Installazione.

AVVERTENZA

Questo simbolo visualizzato sull'unità indica che ci sono informazioni rilevanti incluse nel Manuale d'uso e/o nel Manuale di Installazione.

Deutsch (Nur bei Verwendung von R32)

WARNUNG

BERSTGEFAHR

Lassen Sie nicht zu, dass Luft oder eine Sauerstoff enthaltene Gas-mischung in den Kältemittelkreislauf (z. B. Rohrleitungen) gelangt.

EXPLOSIONSGEFAHR

Der Kompressor muss abgeschaltet werden, bevor die Kältemittel-leitungen entfernt werden.

Alle Betriebsventile müssen nach dem Abpumpbetrieb vollständig geschlossen sein.

WARNUNG

Dieses auf dem Gerät angezeigte Symbol zeigt an, dass das Gerät ist mit dem R32 geruchlosen brennbaren Kältemittel mit niedriger Brenngeschwindigkeit gefüllt (Klasse A2L gemäß ISO 817). Bei einem Kältemittelaustritt besteht die Gefahr der Entzündung, wenn das Kältemittel in Kontakt mit einer äußeren Zündquelle kommt.

VORSICHT

Dieses auf dem Gerät angezeigte Symbol zeigt an, dass dieses Gerät ein entzündbares Kältemittel verwendet. Bei einem Kältemittelaustritt besteht die Gefahr der Entzündung, wenn das Kältemittel in Kontakt mit einer äußeren Zündquelle kommt.

ORSICH

Dieses auf dem Gerät angezeigte Symbol zeigt an, dass wichtige Informationen im Betriebshandbuch und/oder Installationshandbuch enthalten sind.

Português (Somente quando usar R32)

ATE NÇA O

PERDE DE REBEAMENTO

Não permitir a entrada de ar ou de qualquer mistura de gás com oxigénio para o ciclo de refrigeração (isto é, para tubagem).

RISCO DE EXPLOSÃO

Ooops.oeeqo desAgsoo'ene4... .dos. iogde refrigerante.

As válvulas de manutenção devem estar completamente fechadas



ATENÇÃO

5smWmdofofovnoioidona unimdeiod6w.qvaa.oqáade ooniçm P32. m' #s m' ñM iñ#% e ?odom xm ta.DfDa +' foc?feñedeguema.SssseQ2Ldea ocomf508fj.Lmcsmo dg fggde mfge Üg:gx é goseóYögde de n@Qoseenfnw

CUIDADO

Este símbolo mostrado na unidade indica que a unidade deve ser manuseada apenas por pessoal autorizado, mediante consulta do Manual de Instalação.

CUIDADO

Este símbolo mostrado na unidade indica que o Manual de Funcionamento e/ou Instalação inclui informação relevante.

Nederlands (All'a bi) gebruikt by R32)

KAJ STORITI

BARSTGEVAAR

faar no' /uohr ali sen gqsmefigsâ/ 'def kisline ali ö el v joe- Im"ddelcyet je Fd.*a. /eiü'itzte/t/.

EXPLO@EGEVAAR

De compressor moet worden gestopt alvorens de koelmiddelpijpen te verwijderen.

Alle onderhoudskranen moeten volledig gesloten zijn na het pompen.

ZBÌ WAA R S C HU wi NG

"Oui,i'mdo?_o M'... az1' _ \$ szn.da M' z_ib '8 *ö met R32, een geurloos ontvlambaar koelmiddel met een lage brandsnelheid (klasse A2L volgens ISO 817). Als het koelmiddel lekt, kan het ontbranden wanneer het in contact komt met een externe ontstekingsbron.

LEYOP

Dit symbool op het apparaat geeft aan dat het apparaat alleen door bevoegd personeel mag worden gebruikt, met verwijzing naar de installatiehandleiding.

LET OP

Dit symbool op het apparaat geeft aan dat er relevante informatie is opgenomen in de gebruiksaanwijzing en / of installatiehandleiding.

Polski (Tylko w przypadku stosowania czynnika chłodniczego R32)

OSTRZEŻENIE ZAGRÓDZENIE BUOHM

Iedopume \$A'eje h pt: ^dBeni'siø p'a'ePie'"0 m'e\$zân'n gazowej iawiorajacej tlen do obiegus (tj. przewodów rurowych) czynnika chłodniczego.

RYZYKO WYBUCHU

Przed odłączeniem przewodów rurowych czynnika chłodniczego

noge c@TkowiTe z imkn ie wszyktiùh zaworów saviaowycti.

OSTRENIJ

Umieszczenie tego symbolu na jednostce oznacza, że jest ona n Hna "myhn?A wfAídizy P3Z demvönn fpežnym gezem o o'#!ø d*töVi'şp&an% {Ha% A2f zgod e z'n mg ISO 817). Wykcie chłodziwa może spowodować pożar, gdyby doszło do kontaktu z zewnętrznym źródłem zapłonu.

OSTRONTE

L/m/âszcera'e 9o ayri+ao/u na /aiu'tosW. oznacYa, da, veç dj ona obsługiwana wyłącznie przez pracowników autoryzowanego serwisu w oparciu o informacje zawarte w Instrukcji instalacji.



OSTROHNI

Urnieszczenie Vega zym6o/u /ta @.oznecze. 2e w fsfszuk/ obsługi iHub Instrukcji instalacji znajdują się ważne informacje na dany temat.

Türkçe (Yalnızca R32'yi kullanırken)

UYARI

PATLAMA TEHLİKESİ

Soğutucu madde döngüsünün (ör. boruların) içine havanın ya da oksijen içeren herhangi bir gaz karışımının girmesine izin vermeyin

Soğutucu madde boruları sökülmenden önce kompresör mutlaka durdurulmalıdır.

Pompayla boşaltma işleminden sonra tüm servis valfleri mutlaka tamamen kapatılmalıdır.

UYARI

Ünitede görüntülenen bu simbol, bu cihazın düşük yanma hızına sahip kokusuz ve tutuşucu soğutucu gazi olan R32 ile dolu olduğunu gösterir (ISO 817'ye göre A2L sınıfı). Soğutucu gazi sizarsa harici bir alesleme kaynağına temas etmesi durumunda tutuşma olasılığı vardır.

DİKKAT

Ünitede görüntülenen bu simbol, Kullanım Kılavuzunda ve/veya Kufulurn'Xi/avutünde //gÝi oldün makul ö/duğuh'u gösterir.

Română (numal sănd se fdosește R42j AV

ERTIS YENE

PERICOL DE DEFLAGRAȚIE

Nu permiteți pătrunderea aerului sau oricărui amestec de gaz care conține oxigen în ciclul agentului frigorific (adică în conducte).

REC. OE EXPLOZIE

Trebuie să opriți compresorul înainte de a decupla conductele de agent frigorific.

Toate supapele de serviciu trebuie să fie complet închise după finalizarea operației de evacuare a agentului frigorific.

AVERTIMENT

Această pictogramă afișată pe unitate indică faptul că acest aparat este umplut cu R32, un gaz frigorific inflamabil inodor, cu viteză de ardere redusă (clasa A2L conform standardului ISO 817). Pier W 6e ageot fogoo c p4 cvms pancm de apnndsra fu dacă intră üonfdef'in o swsd.'de i'pn'ndars erfmm8.

PRECĂUȚIE

Această pictogramă afișată pe unitate indică faptul că acest aparat trebuie să fie manipulat doar de personal de service autorizat, respectându-se instrucțiunile din manualul de instalare.



PRECAUȚIE

Această pictogramă afișată pe unitate indică faptul că manualul de operare și/sau manualul de instalare conțin informații

TABELA C.ÓNTENTS

1. GE ERALINr.OeM Azlox.	1
2. VARNOST,,X..-..e..-..v..i..e..-..i..o..i..-..,"..l..i..-..0..-..e..i..-..,"..Y..i..-..,"..J..i..-..,"..w..i..i..i..,..i..i..-..i..1	
2:1 A -PLIED. SYMB.DLS.	1
2.2 ADDI7JONAL INFORM.A7iON ABOUT.SAFETY.	J
3. IfdPÓI7'TANT NÓTICE	"S
3.1 INFORMACIJE	3
:3:2 ktINIMUM FLÓOR AREA REOUIREMENTS.,.."	3
4. BEFÓRE PERATIÓN:	"4
4.1 +SPLOŠNE OPOMBE	4
4.1.1 Solocti n of.tke iñstallalJón lócatio	4
4.1.2. Unnad'ing,	4
4.2 FACTORY1U LIED INDO.OD UNF COMPONENT6	5
5. GENEFALNE OIMEFSJONS:	8
5.1 S.ERVICE SPACE	8
:2 DIFNENSIONALNI PODATKI, "..."	A
6. ZA RAVNANJE Z ENOTO	7
7. ENOTA INSTALLATION	USB
7.1 IT DELI (DE GRIPtIONS)	@
7-z INSTALACIJA LJINTOV	8
7:3 REidOvING TLE P "NELs:	8
7.3.1 Removi*B že upper front panel	8
7.3-2 Odpiranje električnega bobna	t9
7.3.3 Ha.ńgińg th% ma9ler conirotlef	10
7.3.1 Po6iiion ft ihe Service vlnó we,.."	11
a. PiPINC.WORK:	11
B:1 SPLOŠNE OPOMBE PRED IZVAJANJEM I?IPING DELA."	11
B.2 REFRIGERAW PIPING GONNECTIDN	12
8.3. w.ATER ó .Ir'iNG GONNGGIION	12
8.3.1 Space heaiing/oolin9 piees.connecCott	II
8.3.Z Ó@ff1 giĘB6 COOFt0CtiOŁ1	1J
8:3:3 Priključek za pripravo tople sanitarne vode;	
	1S
8. OGREVANJE/HLADENJE PROSTORA IN TALNA VODA	
	,15
9.1 AODfITIONAL HYDRALILIC NECESSARY ELENEMT9	15
9.1.1 Ele'menls za sp8cis ogrevanje/cooling	1S
9.1.2 Ejemonts za DHW	15.
B.2 REOUIREIUEANTS AND REGOMIVIENDATIONS for'HYDw.ULEC CIRCUIT'	17
9.2.1 Re'quireri1en@ za arjd-freezi?g	17
9 '2-2 MIIIIJMM fi 'QLIIt. /a.lof Y@.T.Nft1tli2	1 W
9:2-3 Minlimum regulirana voda fx'w	17
9.2-4 Add#ional [information about nydraulič círcuit	17 s 3
WATEFt FILLihIG.....<....	1e
8.3.1 Polnjene vodnega tokokroga	18
9.3.2 ' Napolniti in dmfn'da'nestic vročo vodo tenk	z1
94 WHAT.EP ?ONTI?OL	W
.9.5. DHW. HANK:SELEC1J N	22
10. EL6CTRICAL ANo CONTROL SETTING9	e4
10.1 aENE "xL,CHeCK,....."	24
10.3.1 Inrl ali / na prostem kaamlaslon wirtn	J7
10.3.2 Te.terminal b.oard (Ma'n power suapl.yj:	27.
10.1 Of?TTDNAL TNDO.OR UNI T WR ANG.(ACCEG5.OR TED)	28
10:£ NASTAVITEV ÓIP SwITCtES OF4 PCaJ.	34
11. TESTNI ZAGON	35
11.1 KONTROLNI SEZNAM PRED TEKOM TEGT	35
11.2 CHECKLiSz DMRING.zEsT RUSZ	3S
11.4 PREVERI NAJMANJŠI PRETOK	3S

1. SPLOŠNE INFORMACIJE

Ta maúuel gtvea a common descripflovi and informatJón for this hea pump 8lr cDndltignf which' you op'e'râle as wall. for other models.

Ta priročnik 6hoUlderer bi moral biti stalen del \Teplotna črpalka ali conditlonlbg egiupn+ant anõ sild ostanejo wlth.ll'e air cundldonlbg equlpmnt.

Noben del fls g'uõlcätióñ ne sme biti reproduciran, čopiran, filbd ali canàmitled V' any sliape or form wilhóuł Ihe,peñiñiasfón of kffsénsé.

Vñtiin the polcy of conlinouug improament' ót lts prod\rccts. Hlsonso si pridržuje pravico do sprememb kadar koli brez predhodnega dovoljenja in brez prisile.

Io introdt'cng thom Inio producs pmviously sold. Zato je bil ta dokument med življenjsko dobo izdelka lahko predmet sprememb.

Kot rasult. àpmé óf th'e irñegež ór õara uporabja za illu'atrare lms do ument m'âynot refer No sgecií m'pdefs. No'čtäim's "w1i be øçcgpteõ D'sæd o'n'o'e podatkov. IlluetFatións in öescriptiòns inóudeõ iñ this'manu'a1.

njegova črpalka hgøt qlr conditioner hø\$ je bila deglned fór The leTložIng @mperøMreš. Pteaøg ops-ratg.tha air 'øndiöner lthfn lfiie ranges.

Temperatura

		Min.	Mehika.
Cl'uldaor unlí	u watrg	-zs C ua	je c ua
	DH A D). ' "^^"	-25 °C. Ö8	40 °C DB
	Space cooling	0°C DB	40°C DB
Notranja enota	Prostor lsa hng	15°C	60°C
	E'ome A ho.l wals- (DHW)	20°C.	56 °C 7^i*C*
	'prostor. cooiwg	0 °U	22. °C
	jømpereure. around	5 °C.DB	50 °C DB
	Water pressure	1 veslo	1 bar
	Ps. (DHW Tank Pressure)	-	b bar

DB: óry Bulb.

*: Če je v rezervoarju za toplo sanitarno vodo nameščen električni napajalnik za toplo sanitarno vodo, lahko temperatura v rezervoarju doseže 75 °C.

- Po røcgiving ßr\$ izdelek; |nspect it for.any 6hipping damage: ClaÇma for damegø, apparent oF œnçeataTed, in a wrftøn form., should be filed immediately with the ghipping qgmpøny,
- Chr-ck ße model rtumbo'r. aTectrfcaT charactásbcs (powør øuãgly, vóltagc and fraquoricy) eoó acóésisörioš to detérnnin-a if key are.torect.
- V teh navodilih je treba navesti standardno uporabo urdt \$h'ał exgTgJned. V tem primeru je uühzdüón óf ß'e.unit

- "h r 'hen a Indicaad V uporabi
'nsw "us ni priporočljivo.
- Prosimo, da po potrebi obvestite svojega predstavnika ToçaT.
 - Če imate kakršna koli vprašanja, se obrnite na svojega prodajalca ali deslqneted servics.center of HISENSE.

2. SAFETY

2.1 UPORABLJENI SYI4BOLS

Durirg normal heal pump syslem.desi9n worl' or unit installation, greater attention must be taken attention in certain situations requiring particular.cere in order to avoid damage to the unit. the insllallion or the dtilding or propeny.

Situations that pose a risk to the safety of those in the surrounding area or to the unit itself are clearly indicated in this manual.

Za jasno prepoznavanje teh simbolov se uporablja več posebnih simbolov. situations.

Plaçilo ct äteniTón ló théše syrñbol š aúd to:ih'e messages föflowlng ihm. as your safetý a'nd jhát of others depends on it.

D "Ã N GER

- The text following this symbol contains information and instructions relating directly to your safety.
- Not taking these instructions into account will lead to personal injury or death.

CAMTIO N

- The text following this symbol contains information and instructions relating directly to your safety.
- Not taking these instructions into account could lead to unit damage.

N OT E

- The text following this symbol contains information and instructions that may be use or that require a more thorough explanation.
- Instructions regarding inspections to be made on unit parts or systems may also be included.



Fhfs e Semneis #Heó.wöhÆT]2, an odorless low burning velocity hladilno sredstvo, če je refzžeren nu il,+ifeøled , lßere obstaja možnost

vžig iñit vstopi v rimske jezik z eksfembo/ iñfions. vir.

D A N G E R

This symbol shows that this equipment uses a low burning velocity refrigerant. If the refrigerant is leaked, there is a possibility of ignition with an external ignition source.

RISK OF EXPLOSION

The compressor must be stopped before removing the refrigerant pipes. All service valves must be fully closed after pumping down operation.

Symbol	Explanation
	Before installation, read the installation and Operafion meriuaf, and'he'wirfig Instrucion sheët
	Pred pañfórmniø mainterari% end @rvicai'Nskš read the service manual.
	Za mpri'informøfion, 'he Tectinirel, 'Namestitev'in Priročnik Sorvlöe.

GENERAL INFORMATION

2.2 ADDITIONAL INFORMATION ABOUT SAFETY

DANGER

- **DO NOT CONNECT THE POWER SUPPLY TO THE INDOOR UNIT PRIOR TO FILLING THE SPACE HEATING CIRCUIT (AND DHW CIRCUIT IF IT WERE THE CASE) WITH WATER AND CHECKING WATER PRESSURE AND THE TOTAL ABSENCE OF ANY WATER LEAKAGE.**
- Do not pour water over the indoor unit electrical parts. If the electrical components are in contact with water a serious electric shock will take place.
- Do not touch or adjust the safety devices inside the heat pump indoor unit. If these devices are touched or adjusted, a serious accident can take place.
- Do not open the service cover or access inside the indoor unit without disconnecting the main power supply.
- In case of fire Turn OFF the main switch, put out the fire at once and contact your service contractor.
- It must ensure that the heat pump cannot operate accidentally without water neither with air inside hydraulic system.

CAUTION

- Do not use any sprays such as insecticide, lacquer, hair spray or other flammable gases within approximately one meter from the system.
- If installation circuit breaker or the unit fuse is often activated, stop the system and contact your service contractor.
- Do not make service or inspections tasks by your-self. This work must be performed by a qualified service person.
- This appliance must be used only by adult and capable people, having received the technical information or instructions to handle this appliance properly and safely.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not let any foreign body into the water inlet and outlet piping of the air to water heat pump.

DANGER



Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.

CAUTION

- This product contains fluorinated greenhouse gases. Do not vent into the atmosphere.
Refrigerant type: R32
Mass of charged refrigerant: refer to installation manual of outdoor unit.
GWP: 675
GWP=global warming potential

CAUTION

- Without reading the installation manual, do not carry out refrigerant piping connection, water piping connection and wiring connection.
- Check whether the earth wire connection is correct and firm. The user should not replace the power cord and this must be conducted by professional repair personnel.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Children aged from 3 to 8 years are only allowed to operate the tap connected to the water heater.
- Means for disconnection from the supply mains, which have a contact separation in all poles that provide full disconnection under overvoltage category III conditions, must be incorporated in the fixed wiring in accordance with the wiring rules.
- The appliance shall be installed in accordance with national wiring regulations.
- The installation and service of this product shall be carried out by professional personnel, who have been trained and certified by national training organizations that are accredited to teach the relevant national competency standards that may be set in legislation.
- Mechanical connectors used indoors shall comply with ISO 14903. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.
- Reusable mechanical connectors and flared joints are not allowed indoors.
- Disconnect the appliance from its power source during service and when replacing parts.
- Heat pump indoor unit, controller and wires should not be installed 3m from the strong electromagnetic wave radiation source, such as medical appliances.

3. POMEMBNO OBVESTILO

3.1 INFORMACIJE

- PREBERITE PRAVILNIK.** previdno, preden ZAČENJAMO Z DELOM NA INSTÆLLATION OF THE AIR TO. SISTEM VODNE TOPLITNE ČERPALKE, Feilur'e oči/serve lhe.*nstr? "tlon's for insialiBtk', My.and opefetion %'sc'ribad irt Biš documenta'tloñ mey re'sult v opg'rafirig fállors vključno s potientialy. sariouy foulis; ór a'ven ihe oastrúctiōn ofi thy thy eir'To wetef hit.pump sistem.
- Verify. in aoerdonca mRh the manuels:which aqpear V tñø.outdoor end.Indoor units. tñet al! i ie informacijs required for the correct installation of the system is. Vključeno. Če njegov i a.not Cass, kompaktni wlti vaš deafer.
- Henzense zasleduje.politiko izboljševanja óonknuós In-yroducl design in perfCernan-ce. refIBerarir charge 'mt (kg). end.ions the inshYlla reserved to very. spocifikations wilhóñ nobce.

- Hiséñse'cañnot anlicip'aše every pa6sible'órc' utaüce might Involve'a pöfential. häza'rd...
- This air ro' waler heat pump h'as was desJgnéd fór r'aräa. standard wate'r heating for human beings only: Do not sistem rëft Merge lh'et ouTO be relëa'sed'lo' uporabiti za ólher funkcije, ki niso vključene: V območju iridoor In c'as'e of urdet@teô refrigerati@k. ma'ster'oñncoller.
- Nobenega dela priročnika lcls ni dovoljeno reproducirati wlthool esfebiis'ed z EN.3T.8-1:201G in ISO 8T. pisanje.

- + če imate kakršna koli vprašanja. se obrnite na svojega prodajalca. " Ch'ack arid mak'e sure.that ežpianalions of:each' yan'.ñf hirs manúal cõrespon'd Aeo your air tö'water heàl yump módel.

- + Refe'r.tó tfie models.cedificatiōn to cónlirrn th'e niairi chäraćterističa.of your system.

- Ø Š g 'naT besede (OPOMBA: D. NGGR in CAUTION) se uporablajo za opredelitev ježel ..of hs*ard.seriousness: Dglineton.s za prepoznavanje čudovitih nevarnosti so na voljo na začetnih straneh ol' lcls docume.nt.


- Ø Načine delovanja teh uriitş.ere-cgnfzoT|ed z" masTør o0nÆijer.

- This manüaT should bã oon\$iderod aä a pørrPanenT del ót tie sir tó wäätär Lieät pümp. T'gives a cõmm'on. deäcFiqtiōn of and Information fõr this hellpu'mp'ipdoor enota.
- Keep.thé wetar terrperatui .gf Bi'e'syñ@m aóovg.the frøøzTrig t'ërrig'eratu ê.

3.2 "MINIMALNE ZAHTEVE GLEDE TLORISNE POVRŠINE

- Padajoči kanal in tabela prikazujeta ihø mlnlmum floôr aréa () requrlèd For the installátion of an indoor unl fróm a rafrlgeæent system oonlalning a certain refrigerant char'ge () of R92'(A2L refrigerant), end Supposing a lolat room heiähl not lower lhan Z.2 rn. V skladu s tó 'IEO 60335-2.2018anö EN 378-1:2016j.
- Za -1,84 kg, IEC 60335-2-40:2018 in EN '37a-1.gg16'do nsl esläblisñ any mlnirñum floor area restriction: In lhal case check tooäl re'gulatio'ns la:ensure

$A_{min}(m^2)$ Installation restrictions for indoor units using R32 refrigerant



$$A_{min} = (m_e / (2.5 * LFL^{(5/4)} + h_0))^{2/3} \quad (\text{EQU.1})$$

: Minlmum namestitev areo'a lndoor enote.za gl hé right 1s therefore

- h". InàualTation nčligh ofl ñottom siõe of fliè-u' - nil - lhal dis an'ca fróni ttia iñounll bôrrom'side O.ih'e ñwešl pa'rt for which a "refrigc and @R rroý raæasà to thë 'n'
- LFL - spodnja meja za R32, 0,307. kg/m? je

m _e (kg)	Winlmumfloormeefore0umnenimaa#eo vozlišče		
	A _{min} (m ²) Floor mounted	A _{min} (m ²) Wall mounted	A _{min} (m ²) Ceiling mounted
1.84	26.81	3.20	2.14
	30.72	3.41	2.29
2.0	37.53	3.78	2.53
	41.11	4.17	2.79
2.2	41.11	4.58	3.06
			3.35
	#9.02	5.45	3.65
2.6	oz.oa	6.38	4.28
		6.89	4.61
2.8	ob.IZ	7.41	4.96
2.9	z1.Torej	7.95	5.32
		8.11	5.70
	81.79	9.09	gUB
	87.19	9.68	6.48
3.4	52.68	10.30	6.69
3.5	104.26	11.58	7.75

Ihal ng hard re'stflct<ns m9y aäply.

- , v ifie abu" bo-e je wrulatød ärd=
" ihe form'ula (EQU.1) un'der the'foln
'g. conôl onâ.
- Fõor mnunléğ: $\tilde{G} := D \cdot 6m$
- Stenska montaža' fnâ = 1.Bm
- Ceiling mounted: $h_e = 2.2m$
- For safety, the A_{mn} must be calculated according to the actual installation by professionals.

PRED ZAČETKOM DELOVANJA

Hrsense

! CAUTION

- Do not charge OXYGEN, ACETYLENE, or other flammable and poisonous gases into the refrigerant because an explosion can occur. It is recommended that oxygen free nitrogen be charged for these types of tests cycle when performing a /øa/röpe zestr ali ai Gasanekaj. Šahovske vrste guses-
U"
- Insulate the unions and flare-nuts at the piping connection part " "
- Insulate the liquid piping completely to avoid a " " performa if not, it will cause sweat/10 e.surface of one pipe.
- Charge refrigerant correctly. Overcharging or insufficient charging could cause a compressor failure.
- Check for refrigerant leakage in detail. If a large refrigerant leak "a9a oocup. ff povzroči d@curly Oh bre4/7i/zg ar harmful gases would occur if a fire were being used in the after a long time and cause refrigerant leakage.
- The heat pump indoor unit is suitable for the floor mounted condition ($h_0 = 0.6m$) for most installations.

4. PRED ZAČETKOM DELOVANJA

4.1 SPLOŠNE őOTE

4.1.1 Set.ect4on ól the Insteštešion io.cetton

Notranji unišmu9t biti vstavljen v skladu s temi osnovnimi zahtevami:

- Indoor unit je spremenjen tako, da ga je treba vstaviti v zaprt prostor in lo'r ambiènl.l'emgeratúrëä rar'gip0 5-30°C. V bližini notranje enote mušt õe. više od 5°-C la prèven\ waler from freezlng.
 - Prepričajte se, da je lhăt s/electđed floor ls'llal.'srong enough' for suçportlñg ltte notranje enote weight.
 - Prepričajte se, da ohranjate priporočeni prostor za servisiranje za popolno delovanje enote in zagotovite dovolj zračnega prostora okoli enote (glejte poglavje "5.1 Prostor za servisiranje").
- e Vzemite v šóou'nt da sh'ul-ol ventil s filtrom (f"clory supplied) must bo inšalleq' at the 'ndoor i'nil iniet connëctions.

- Poskrbite, da voda odteka po določilih. Varno valVe je piø'viðe'd s.drain cevjo, ki' eæ iocatëd älfie drain 'pän'öf enote.

- + Pröta'ct th'e lidoor 'unt'aðajn'sr th'e an öl èmañl :enirnaiø (Irks rake) which cglud mašinä cqntäqt.with °ltia wires\ the.öraln pipe. electričal paM and mey demage unprotoeO'd p'añs, arid! at th'e worst,. fire wiil 'ocur.
- V "sta|T ga v np-frgst önyironment;
- Ne iristalT enote v vratih v Tócation.wlth 'vary h'gh vlažnost.
- Dó ne namestite indöör ont wnere a4ècfromsgnët!ç. wäVeš so diFactty seval, s alactic8l bo*.

- Namestite \he unl na mesto, kjer v primeru vode uhajanje, ni mogoče izdelati nobenega damaðø to lire Instašation prostora.

- Install noise filter when the power supply emits harmful noises.

To.a oid fife ali exploáion, dô nót ïnäläll th'e unh 1n '+ fammabè envifonmønT,

- The air to water heat pump must be installed by a servisni tehnik. Irstellat mora biti v skladu z lokalni in evropski predpsi "


<. Poskusite se izogniti postavljanju predmetov ali orodij v notranjost.

4.1.2 .Unpacking

!!! enote ari zapakirane z lesnimi peleti in cerlòn esširñoly. Firefly to'unpad' it, pläce the Unit on the essemby area as ck'sø as possible tó its:final InstallalJón loiga]òri, Ø avoid óama0es In transport. Zahtevata se dve osebi,

1 Odrežite. stra piN§ baFld6 'ä in odstranite lepilne trakove. 1 Odstranite kartonski sklop in odstranite plastično vrečko : okoli enklave.

Carton Assembly




DELOVANJA

•¹⁰

FACTORY-SUPPLIED INDOOR UNIT


o,
biti tla, čim bližje lokaciji lirrsT.



4.2 3 Ramovefhe 4 noge v obliki črke L na 4.comers.and Uten

Cnotranjo enoto iz woodan p9..in jo previdno namestiteT OMPONENTI

ACOOL ALI	Image	Qty.	Remarks
Oaslei		12	12 gaskets for each connections between the indoor unit and shut-off (6 of G1" and 6 of G3/4")
Shut-off valve with filter (G1")		1	Connect at the water inlet éTiVoorVnM: usedlo#43 og be we ter gow eno filter impurities in weler.
Kabelska kravata		3	Used for wiring binding
Drain pipe clamp		1	Used ft fasonIng. dtain tema ana draln pipo.
Cevovod za odvajanje vode -		1	Used for drain hose of pressure relief valve
Instruction mn "al		1	Ba.sic iisTractions za davlce.
valve pressure relief		1	Uporablja se za razbremenitev tlaka za pripravo tople sanitarne vode



NOTE

- The previous accessories are supplied inside the packing assembly (on the top of the indoor unit).
- Additional refrigerant piping (field supplied) for connections to outdoor unit needs to be available.
- If some of these accessories are not packed with the unit or


CAUTION

- Be careful with the Installation and Operation manual and with the factory-supplied accessories located on the top of the unit.
- Two people are required when handling because of the weight of the unit.

SPLOŠNE DIMENZIJE
S. SPLOŠNE DIMENZIJE
5.1 SERVICE SPACE


l-isense

Unit: mm





5.2 PODATKI DINENSIONAŁ

Unit: mm




6. DO I-IANDLE Tf4E UNIT

- + Enoto previdno nagnite v slabo smer, da bo ročaj viden.
- Za prenašanje unira uporabite Sandlasa na bac+ in na dnu.
- Zaradi teže enote sta pri rokovanju potrebeni dve osebi.



- Naj bo lne univ venlcally, lilll dackwaro (tlit kot manj ll4an 1") je dovoljeno, medtem ko je prepovedano, da se lilt naprej




Namestitev enote



7. NAMESTITEV ENOTE

Y.\$ GLAVNI DELI (OPISI)

Ne.	Pai-l
	Upper front panel
2	Lpøer front.pa?el
?	9ldo panut
'4	Msster coritrolTur
6	Hue' za ožičenje
7	Win'dòy fp'r cfiarge pon of cxańston
	gtr.pugö 'aivó




- Da bi preprečili, da bi se notranja nit prekucnila, je priporočljivo, da fis Uporabite enoto na greund fry štiri L-snaqed feat z 8:sidrni bolss fM6}:



7.2 Namestitev UNfT

- Prilagodite prosti tek, da bo ustrezal talnim irrgularitias. Ti e mRxlmuntn allo'wed deÝlaii'n I\$ 1",




7.3 REk#OVINJANJE PANELOV

i\$ n ssary to aš\$ to the indoőr unit čomponentz: pleasea follow fhaše ďoparations,

7.3.1 Odstranitev zgornje sprednje plošče


1. Unscrew 1 screw on the top of unit

The indoor unit front panel needs to be removed for any task inside the indoor unit.



2. Remove the upper front panel.

KORAK 2 Potisnite sprednjo stranico naprej, odstranite zaskočni del in ga obrnite navzgor.





Step 3 Pay attention to the wire connected master controller and electrical box. Do not pull the wire, otherwise may cause the breakage. Unplug the terminal to release the upper front panel.

7.3.2 Upravljanje električne omarice


NEVARNOST

- Disconnect the unit from the power supply before touching any of the parts in order to avoid an electric


"Henile na elaci@l polje coyer oan se uporablja za obešanje glavni contrc4ler.



Step 2
The electrical
box cover can
be opened
about 120°.




Step 3
Unscrew
the 3
screws.




4. korak Tle eTec@r@f óox lahko bc tumed Bbout.93*

7.3.3 Obešanje glavnega krmilnika




CAUTION

NOTE




Korak 2 Obrnite krmilnik Imre
clockwise to separate conhoBer.frame

Steg 3 Vstavite izlojhe ročaj.



Step 4. Complete hanging.




CÄ.U T I O N

Be sure to remove the battery spacer of the main controller before turning on the unit.


7.3.4 Položaj oken servlet Mndows

Step 1 Unscrew the 1 screw to reach the charge port of expansion vessel:



Step 2 Unscrew the 2 screws to reach the air purge valve.

Charge port of expansion vessel.



8. DELO S CEVOVODI

Make sure that refrigerant piping installation complies with the legislation EN378 and local legislation.

8.1 SPLOŠNA OPOMBA8..PRED IZVAJANJEM DELO S CEVOVODI


- paæ toæetljäu ppled çopper.'pipes.
- + 9izberite velikost cevovoda z lie Correct Ihiness änd ørtecl material sposoben w.fthštan'd 'aúfficie'nt p'r's'säure.
- + 5elæct sleän æpge'r p|pes. Mahq..sure th'at th'e're. li nò óust'or trio\$Tér.e.'InSide th'e.qipee. Pihajte iriside! pipøs w*h'.ôxygen'fre.s riitrog'and lo remova .any dust'an'd fóreigFi materials befo're..conn'ecting th'em.

N O T E

performance and life cycle compared to that of a poorly prepared system. Take particular care to ensure that all copper piping is clean and dry internally.

" Cap Ifie konec tega pipg ko pip'a.ie biti "InBertgd thróugh a well hole,

- òo net pù.t piqeš ön lie gFound directly witho' l a.æp or vlny| Tape af Ĝe en'd of the ģi@,,




- Če se namestitev cevovodov ne zaključi naslednji dan e. v daljšem časovnem obdobju; spnite konce cevovodov. zaključite polnjenje z brezoksidnim nitrçenom skozi Schraderjev spojnik 'give type:acoess, da preprečite vlago gr+d part'de Gon@rz1inatlion.

ø Priporočljivo je zavarovati cevi. spoje in connéctions v ordei'to' evoid heat loss @n'd öeÑ Condensation on the'.surfaoa-of4he pipas "or acciden'tgT injiu'res due to exoassive head on piqirig šurtacëa.

- Òo n o t 'uèe' iriøulalion 'ciateriel llat"çontains' NI-L. as.it 'cán damage copper pipè meterial in becpnr'e a source öf ßAre le'ak'age,
- To la.rëcommeñdeó uporabiti i1e*ible jolm" za wa'gr pipin' Ince1 en'd ou0at in otder.to avoiò sibra na trer'smiaalón.
- Refígerant cirauil in vodni krog mora opraviti in pregledati licenciran strokovnjak in mora biti v skladu z vsemi ustreznnimi evropskimi in nacionalnimi predpisi. nacionanlimi in drugimi predpisi.
- Po opravljenih delih je treba izvesti ustrezno Inspeelton vodovodnih cevi, da se zagotovi, da ne bo prišlo do uhajanja vode v obtoku.

- Lor0tion hladilnega sredstva in vode Pießline UM *h " CEVOVODA




8.2 PRIKLJUČEK CEVOVODA HLADILNEGA SREDSTVA

Pipinj priključek Velikost notranje enote je prikazana spodaj.

iZoRJ	F-e* devet.	Li+rū a mm
ueelj 0 OR1	Ø 12.7 (1/2")	Ø 6.35 (1/4")
060(2.5HP)		
uaui(3.UHP)	Ø 15.88 (5/8")	

Potrebni navor je prikazan spodaj.

Pipe Diameter	Torque(N·m)
	14~18
Ø 9.53	37~42
Ø 12.7	48~61
Ø 15.88	63~77



NOTE

Screw up the nut cap by two wrenches. Heat preservation material on site should be used to prevent heat leakage of gas pipe, liquid pipe and connecting nut cap.

8.3 WATER PRIKLJUČEK


- Piping connection size of indoor unit.

Model	5p:are ozdravite cootlr 'pter i z	E'HW Oullef DHW lütél (HubA'atet' (Cold) coul-i q watt	kobila zdravljenje' nU'tlet
0-t4 (J:0HR)	G1" (female)	G3/4" (female)	G3/4" (female)
060(2:5HE)			
080t 8,0 PIP)	Torque Required	40~50(N·m)	

8.3.1 Priključek cevi za ogrevanje/hlajenje 9pace



- (1) Namestite vrednosti shut-off

Izklopni vè s flTter je na voljo z uftlt:Far čon'venzenoe oT rep'alr ar\dl mai 4£er+an'ce. instalJ sñu£-o f ventil wlth ü IU an wa ter inlet yipe Indóor enote kot folTa^/vs. 'späce hëaflng/coofing inst'altung can b è "cárried 'oul wferring tci 's'electio/ 9.1.



N.O.T.E

The shut-off valve can be connected to the water outlet of indoor unit directly. The shut-off valve with filter must be installed at water inlet of indoor unit, and water flow direction and installation direction must be confirmed as shown below. The gasket in accessories can be installed at the two connections of shut-off valve and shut-off valve with filter.



Step 1 Insert the drain pipe for the safety valve

CAU TI 0 N

- Rubber gasket must be mounted (factory supplied), otherwise damage may occur.
- Do not remove the drain pipe from the safety valve, and do not disassemble the valves and drain valve, which are essential to maintenance.
- Screw up shut-off valves by using two wrenches.

(2) Dodatni filter za vodo

C A.U.T I O N

Provide a 50 mesh or more water strainer at the water inlet side of water piping. Otherwise, damage to the plate heat exchanger may occur. (50 ali več mrežnih očes je primorljivo)


Water Flow Direction
Water may flow through a narrow space between the plates. Therefore, there is a possibility that freezing or corrosion may occur if foreign particles or dust clog the flow of water between the plates. This is not required when cooling mode is not used.



utripa on wener'sys/em.

8.3.2 Odvodnjavanje plpee connection

Za pravilno odvajjanje vode, priključite odtočno cev za ta unil na Splošni odtočni sistem.




NOTE

- The safety valve is activated when water pressure reaches 3 bar.

Sép2

OsaMlhe dam ppmol
mdoo un# oomp lo to
the end of the hose
connection.

Fasten the drain pipe to
the drain hose with the
factory supplied clamp.



Step 3
Insulate the drain pipe after connecting
the drain hose.

N O T E

- Check if water flows without obstruction.
- The recommended drain pipe of the indoor unit is polyvinyl chloride (PVC).
- Ensure that the drain pipe is firmly fixed through the clamp, otherwise it may cause water leakage.
- The drain pipe should always be open to the atmosphere, free of frost and in continuous slope to the down side in case that

8.3.3 Priključek cevi za toplo vodo


- Povezava med vtičnikom za toplo sanitarno vodo in priključki za toplo sanitarno vodo v notranjih prostorih mora biti izvedena ob upoštevanju naslednjih zahtev!
 - Namestite tlačni izpustni ventil (dobavljen v tovarni) na OHW Vhodni priključek (čim bližji vhodu za DHW rezervoar), da se zagotovijo naslednje informacije.
 - Zaščita pred pritiskom
 - Nepovratna funkcija
 - Shuz-dovm valvB
 - FITting
 - Odvodnjavanje

V nasprotnem primeru je treba za vsako funkcijo namestiti poseben program.

- V ploščici za priključek DHW ouf/ef namestite tudi zaporni ventil (priložen je fJeld), da bi olajšali vsa vzdrževalna dela.

OHW o-ile

/ .DHW Inl01



8.3.4 Izoliranje vodovodnega priključka


- Cevovode v celotnem valjastem okrožju MORAO biti zatesnjeni lo prevenl andenBation med hlajenjem in zmanjšanjem hentinga in hlajenja. capacity.
- Če je temperatura višja od 30 °C in vlažnost zraka večja od RH g09, mora biti tilnik 6 maleriata vsaj ZO mm, da se prepreči kondenzacija na zgornji strani Insutacije.

NOTE

For more details, refer to the section "9.1 ADDITIONAL HYDRAULIC NECESSARY ELEMENTS".

DAN GE R

Do not connect the power supply to the unit prior to filling the space heating circuit with water and checking water pressure and the total absence of any water leakage.



Name	No+	Part name
Piping connections	-	Spine nevunn/ 'nn -ete+ im
	ž.	Space.neasing/Wing voda ouiae
	u	DI-ty ml'zdaj w-aizer
	4	DHW outlet (Hot water)
Factory supplied	5	Shut-off valve with filter
Optional	6	Cooling
		Thermistor (for Space heating))
Field supplied	8	Shut-off valve
	9	Water pump
	10	Filter
	11	Ml moj ventil
	12	Check valve
	13	Shut-off valve

A6 vgradnja eXBmpTe sgace. heating / Cooling. thø
following hydraulic elements are necessary to correct.
perform Cha space haating / cooling water circuits

- The ffele"supplied'shut-off valve (a) need to be Installed
ml aler uiie of he untL enrl shut-off vak'e with filter
(5) need:ls be Installded hoùzontally ai Paler inlët of lhe.
unit:
- Kontrolni ventil za vodo (12) vrlñ 9 zaporni ventil (13)
mora biti pri polnjenju valjal-le.povezan z dlanjo za
polnjenje vode. Ta, hed' vilvs, je kot varnostni odklon
lo grotiéct \nsial|aúo'n.

wälør ?utlet plpe:of spøçific inställaiõn. us'ed ió divert ihë weler.cirć'ulaüsñ for spøçific funsüons,


- Sqaae.heáng thermisor (7)
mora.bitü.nameščen.na.meIT.lube.close.to space
healing; in obdržati v goad
- Mešalni ventil f11) je priporočljivo uporabiti
ESBE ARA661, nosni ogrevalnik je 3 olnt
SPDT. Če se uporablja ventil drugih znamk ali
modelov, je način delovanja 3-točkovni SPDT.
in pöwer
napajanje mora biti 22&-240V -. 50Hz. Vrtilno
frekvenco lahko nastavite v glavnem krmilniku.

9.1.2.. El'ernents 'za OHW

Kot 'Insiallakon primer ōon'estlc hot waler (DHW), lhe
lóllowlng hidranlični elèrn'enls so néoässärý ló cooesiiy
perförm' tl+a DkJW wäler ójo+lt':

(1) Elementi /egüired før the DHW watar circuit

Nøùure	za.	Parl uation
connections	2	DHW outlet (Hot water)
Field supplied	4	Draaining
	5	Shut-off valve
čöctory. euppfeid	6	6a Nat+n d+øck uah/ø br P'renaøre n-e- -n've
	7	Orain ptqB



• A zaporni ventil fiatd suçpliad).

Ventil (5) je treba po namestitvi rezervoarja za toplo
vodo (2) v "õ'rder tó make' eäšier er+y m'alntenenco
work.

• Pæaeura rellaf vslve (tovarna Bupp}led):

TLiø.dornöstlc rezervoar vroče wstar mMst bø napajan
wlth cold welør pas6ing skozi preßšuru relief veTvø (g)
çelsbratèd to: ebo+Jl 7 bør (dopøndlng on local
reguleóons}.ßqerate 4e qres\$ure røTlef vpTve
aCçordirig to manufiact rar.:ø sgocificafipn,Med
qwssurø røTiaf else (8) arid thø tsnk ne sme biti
nobenega drugega ventila. lačni
relief v lve (.6) mora biti nameščen čim ližje DHW

inlet in çgnrectød lo.,a drajn pipe (?) leading te
sawwer. Ta tlačni rsllef ventil lahko zagotovi
naslednje:

- 9+e9sure protecdom
- No?-retufri tun'ction
- Filflrig
- Öminimg

check'lhe pre'ssura.re lief valve oń thø .oid.wa'ter šueply
inlet.

Redno upravljaljte ventil za uravnavanje tlaka, da
odstranite usedline in preverite, kaj je v vozlišču zamašeno.

OGREVANJE/HLAJENJE PROSTOROV IN POMIVALNA VODA

Hrsense

Specifcaions fór prëssure ref'ef valve'(6) (Fë'clo / supplëd)


Rélet P eesure: 0.7J'.0:05.MPÚ

Water flow rate:

Užitek g-ifTerančei "MPa	0.05	0.10	0.30
water flow rate L/min	7.2	10.0	19.8

Instručiōns fór prëssure. rellef valve (6) insla1latiōri:

Prepričajte se,,da je dreinaže outlet lhè pressure rélefef valve is do'w'n'ward for complete dreinags.



NOTE

The drain pipe should always be open to the atmosphere, free of frost and in continuous slope to the down side in case that water leakage exists.

/he "vsota". fvave:b bëop#%àU Wa/aæmòæ aep1i'm'ndb...e"rp^a' is. ó :

KAVTIRANJE

- DHW tank supplies hot water from tap water. Domestic hot water is only used when tap water is connected.

sJ2Do, Vojnañoe1'm0 1äd Nnhå "leV#sn#Hr0ff/ leaks.

- When water hardness is mòre than 250-300 ppm, recommend using softened water to reduce DHW tank scale
 - Immediately flush DHW tank with fresh water after installation.
 - Flush once every day in first five days of installation and the DHW installation in order to decrease possible temperature losses.
- If the domestic cold water entry pressure is higher than the DHW tank's design pressure, a pressure reducer must be

After used for a while (depend on local water quality and use frequency), clean DHW tank and remove scales.


- Power off and close water inlet valve.
- Open water outlet valve and drainage valve to empty

CAUTION

When scales are removed, temperature in DHW tank y be a little high, it should prevent burns or drainage equipment damaged.

- Close drainage valve after cleaning several minutes with water inlet valve opened. Ensure effluent water is closed after DHW tank is full of water. Power on and get back to work.
- éra/SñVOH fän aëfsènmun#nr0o %c%m aü waiáz'u iinrasedleeDfng.öoiavå'u'mà .

(2) Elemenla ragulæd foi the DI-M recimutalion cirlull



Natu+a	Ne	Pan name
Piping connections		uuw inlett oio .weter'
		DHW ouuet lo4 wafr{
Polje. stipp6ed	o	Wat wet
		Di4yy črpalka
	5	Shut-off valve

- Črpalka za toplo vodo (dobavljen na terenu): Ta p'ump' OHW (4) bo pomagala' pravilno recirkulirati tul waler v.DŁJW inot. Opti'ralna ouput funkcija DfñW pumy {oöde o-13X:an bää üöt za pogon "relay of a DI-W pump ifi case of DHW pump is äväilable, referririš Ö 10.4.
- A Kontrolni ventil za vodo (dobavljen v kompletu): Ta,dostop t3) ūs. cennected. after tag DHW pumn l' da bi zagotovili, da se bo Watgf vrnil. Dva Shut-oP velvea (polje: dobavljeno) (5): 'On pred lažjo DHW'črpalka.(é) in druge aRœ voda preverite dodatno opremo za vale (3).

CAUTION

Tlfe DHW ianfi.: la' egui oed Ü/h a.äafe/y //iermóstal in öj-erar'ng remgëcsrure a/ the: aarety the'rmoérai.'n/# öe af(eected.Gy ifie "a/i?ude {ormosg/ie/c pressureJ. M8že èure max. DHW temperature NOT higher than the following value.

Altitude (m)	Atmospheric pressure (mmHg)	Max. DHW temperature (°C)
4000	424	75
6000		
8009	256	63

Hixenøe

8: ZAHTEVE IN. RECOMMENDATION za HYDRAUMC CIRCUIT

9:2.1 Zahteve za zaščito pred izkrivljanjem

- Ko je ena enota zdrsnila med sh'ut-ol' 'periods' and tue anibJenl lerppereiture is very low, the water lrišlde

plpea and'ē čl*xJl tlñg puny may reea. hole9
damaging the pipes aňo the wu'er.ğump. V teh primerih:
Ihë insle1ler sh8ll zagotoviti Ih'Bl ihé' waler ternpérature
Tnsle tfie:pipes does nol fall öeluw Oie fréezlñg pod l.
In order
za prëv'erit lhts. the unll le a self-proteclJón mechänism
whJch bë activaled (réfer to "10.5 SETTING OF DI9
SWITCHES ON 'PCB1'").

- Tudi če je Unil ls:slopped, Me waler pump.may run under s'ome clrcurnštan* s: i.e; 'when the anuřreezing function is trlgiréd.
- " enoto pomol hranite na vodni gladini äystem' unb1ocLe'd to p'reYgril water'freazing, drugivii+e se pojavi alarm n1aý.

- If the water system is blocked, an alarm of water flow se'be' posjyl mopped Za dolgo perild imø v w "n r. i te stag, celoten sistem, ven weter V vezju am4.watør cevi za preprečevanje freezing:
- Th'- anti-freežng' protécüön je učinkovit beltör.with Auffiliary eleclzic heatér'connected. Če je'.advi9BŁlje la iristall tfia Aú*liary aldčrlč' he'atör "för th'oše m'o'deTs'in whä:theae'ar úot ugpljed at options.
- However, in case of a power failure or unit failure, te fun'plionś ne more'.gue@n'tíø pfotećoo "n.

9, ,2 MtnIMUUm æQuTred w8tØ£ VOâUM6

Naslednji del šhrzrš mtnlmum waler úolume v šhrzhe syštorn' fgz'product protection (Anti-hunting) eñd femperafuré povlecite al odmrzovanje.

- Minimum required water volume in each single water circuit of DHW / SWP for product protection (anti-hunting). Water volume in each single water circuit of DHW / SWP need be greater than 20L.
- Minimum required water volume in single water circuit of space cooling for product protection (anti-hunting). The following table shows the minimum water volume needed in single water circuit of space cooling.

hüael	tl4 060Ç 0hIP SHP-	080 .0E4P'
Minimpm test n=0 water volume	gdL	4L

- Minimum required water volume during defrosting. The following table shows the minimum water volume needed in single water circuit of space heating in case of safe defrosting.

Lowest possible operation waer tempoeä ture in slngfe waier'clcul'oT 'spmce hëating	Q4-4/0g0 {2tO2. s.HP)	oaô s.0t4P)
225 °C	61,L	61L
20-25 °C		mL
15-20 °C	158 L	E8L
10-15 °C		waL



- The values shown on the table are based on theoretical

OGREVANJE/HLAJENJE PROSTOROV IN POMIVALNA VODA

- To calculate minimum water volume the internal water volume of the unit is NOT included.
- Consult with local technical engineer under the special occasions where operation water temperature in single water circuit of space heating is lower than 20°C.

2.: 'Hnlmum equirad wa'ar "fow

Ct écl' da je vodna črpalka lhè wa'ter ciruit werkä'with1n ltie pump operaüng. ran'ge in lhät the.hater'low is over'th'e unit minimum vaiua'.

.u-dei	Min. wajgr l1nwfl/mm J
LPlotZ.UrtPy	8.3

9 2°.4. -Dodatne informacije o hidravlikì Ú JG t

- An additional special water filter is highly recommended da'namesteesa sporečteing' add' Namestejo' od örazjng'yhish, ki jih ni mogoče odstraniti z dobavljenim poljem shut-off valve with filter.

+ èuf Insula'tloń in th'e:pipe.1n da la avód ileal lo'ss.ss.
' kadar koli.posäiule,:sfuicø vøNes sheuld biti nameščen za vodo plpińg, In ords Ø.miüimiže fJøw.'PB6istance.and te mnintain.:suftislenl voda fluw.

ø Enäure tit be instation cemplieø z 'applicabéé
'gegi6lati6n' in ternis of piping c'pnnäctün arid 'matörnals, nygénic meáuireš, testing and the g ibØ fequlrqd uporaba eume posebnega cempsnen6.T thgrmo6lc.
+'-'ce valvei.

+ Največji wà'r prgBs'ure:je 3 dar'(nöminal ópening pæss'üre od sefety valve'). Frcivldé' adeguale reduction pressure device in the water circuit to ensure that the maximum pressure is NOT exceeded.

- The water pressure can be read on master controller, detected by the water pressure sensor located at inlet of plate heat exchanger. If water pressure exceeded 3 bar, the water pressure displayed on master controller would flash.

• Ensure that the drain pipes connected to the safety velvø:a.nd do ventila za čiščenje zraka so.pravilno driven Q evpid voda b0inq in.cen@ct paruk enota Comporientg:

- Make sure that all field supplied components installed in the piping circuit can withstand the water pressure and the water temperature range in which the unit can operate. The units are conceived for exclusive use in a closed water circulation.

• The'intemal alr préssure ol the expansion v'essel will be adapted to the water volume of the final installation {factory suppteö w4h ī b'ar notranjega zraka é9sure).

- Dreln tü'p's mora biti,provlded'at all low points:of iha Insialla6on to,permll cemplsre dralnege óf ifie circuit durlng sérvleing.

• TI e največ plng langlh de-ger1ds on the maximum pressure avsllability in the waler suæet plpe. Preverite krivulje črpalke IAe.

- S eir'urge slvo {fact 9.3 NAPOLNJEVANJE VODE dojavljeno) pri be. higheet. Tuiation of thie un't. Če tuis krog lokacija IB ni najvišja od lhe watør insi8lJaüon'. air mlight be Wëped insi0a The'wotør'pipøs, which could 'cause 9ysliam msfunctiòn. V tej čäce additioet 'air purge valves (field supplied) should be installed to zagotoviti nó "zrak ' nterg'the watør Ómit.
- Fór'h-aating Boar šalam, the älr should üe púiqød by meán of an'extemal p'u'mp end an op'Rn circuit tq:a'voîd air bags.

Un#.i9 opremljena 'Nitú. in

9.3..1 To. napolniti theratar

- (1) Preverite, ali je wèta chocít välvé (fioJd s'úpplieü) z "a sh'ut-óe Valve (field supplied) je cón'ueclëö lo'tha waler filling p iMl (water inlët coíneč'iön'.for filli Jg tiydratilic čirc'iR (šee: "9.1 Aôöidonal hýdrauliü nécessáń/ elem'nnts).
- (f2) Make'eure aji ltte' valvea ar6'epen (wa'er inietro txt @ut'-off valves'and the r6st of vaives:öf the wäter ürcuit inBtal\afion compõnefttä).
- Š).Prepričajte se, da je ventil za čiščenje zraka v enoti ig,opgn ,who \Koosøn th'e ccrav cap.of sir purga yaNe. qroparly lø œmpleialy dhscharpa tha air inšide a.nd ønsüiø the air purga vahøe is open},
- (4) Preverite l sit Who drein pipee Connoqted. to The.safoty. vejvø (keep Its outtét of drain pipes [oca\$ed.in the drain pan) are' correctly connected to Who gønenat draining.eystem, The øsfe\$ valve.ia'T8tor used ee an eir.purging:davicg during Who watet fil1ing qrocødure.
- (5) III 、 Vodni krog z wata-r ontll gréšeuìè prikazano ön' lh'e.cóntröTk-r reà'ches 2,0 z 0,2 bar. Med vsemi.th'ë ogeratiön'čorióíðan'8 je lhë normalna pr%a'sure ran'ge' pri utatúr clrcult l2 ,5'bar.


N O T E

While the system is being filled with water, it is highly recommended to operate the'saë yells menoefly so os to he/g wfl'n who all P"@.Æ en't'reduie.

- (6) Odstranite čim več zraka Fom inslde:lhe water člcuit as- possibla through ihe air purgø value and olher air vena: in \he installation {fan coils; radiators...}.
- (?) Za začetek postopka al'rpurge sta na voljo dva načina:
 - Z uporabo glavnega côntröJlerja lo zaženite čiščenje zraka. (glejte priročnik ltie rñaáler cõntro!ler)
 - Uporaba DgW4-1 na tiskanem vezju ltie PCB1: DSW&1 ON:'Start air purge. DSW&1 OFF: 8tog air p'urge
- 8) If e liØe'đuanü of air'is Still rem'aining in' ßo Water cimujt. \l +tll se odstrani z':au£omatić'elr purg-e ventil f Ifie enota du'rlhg ltie prvi houis f o'peretion. O'ricè tue 'air in .be:inštoTlatlon W\$: been removed,'a reducüon ol water. pressure. in órauit is very likely0 oMur: Th'erefore;.addiTion'ai watai shoulô be fille.ñ by böoslier pump until wà te.č preßsurä retu fiis to a prožimäte 2..0

L I N O T E

- The unit is equipped with an automatic air purge valve (factory supplied) at the highest location of the unit. Anyway, if there are higher points in the water installation, air might be trapped inside water pipes, which could cause system malfunction. In that case, additional air purge valves (field supplied) should be installed to ensure no air enters into the water circuit. The air purge valve should be located at points which are easily accessible for maintenance.
- The water pressure indicated on the master controller may vary depending on the water temperature (the higher temperature, the higher pressure). Nevertheless, it must remain above 1 bar in order to prevent air from entering the circuit.
- Fill in the circuit with tap water. The water in the heating installation must comply with EN directive 98/83 EC. (example, water from wells, rivers, lakes, etc.)
- The maximum water pressure is 3 bar (nominal opening pressure of the safety valve). Provide adequate reduction pressure device in the water circuit to ensure that the maximum pressure is NOT exceeded.
- For heating floor system, air should be purged by means of an external pump and an open circuit to prevent the formation of air bubbles.
- Check carefully for leaks in the water circuit, connections and circuit elements.
- During water filling, it is necessary to ensure that water enters the unit from the water inlet to ensure that all water passes through the shut-off valve with filter to filter impurities, otherwise it may block the components inside the unit.



X O T E

- Enota olje/leg fblaT vsaj 6 mm Pred razmaševanjem nesf zraka pHrge eye/e.

OGREVANJE/HLAJENJE PROSTOROV IN POMIVALNA VODA

Wrsense

English

(9) Preverite obseg Watèr:

Unil je opremljen s posodo za razprševanje BL, privzeti notranji tlak pa je 1 bar. Da bi zagotovili pravilno delovanje enote, je treba prilagoditi tlak v posodi glede na predvideno količino vode.

- Uporabite spodnji pregled količine vode, da ugotovite, ali je treba prilagoditi začetni tlak ekspanzijske posode.
- Uporabite cherklis' volumna vode za vejico skupni volumen vode v 'nstallation sistemu je pod allqwed maxinsrin volumen vode.
- Installation height difference: height difference between highest point of water circulation and the unit. If the unit is mounted at the highest point, above all water pipes, the installation height is deemed to be 0 m.
- Calculate initial pressure of expansion vessel. Decide initial pressure (P_g) according to the maximum installation height difference (H), seeri below:


$$P_g = H/t_0 * 0,3$$

Unil:H (m). Pg (bar)

Watèr VóTume:Kontrolni seznam

	Instal lation h'eigh£ dihören'ce (e)	Wa£er Volume	
		s220L	'220L
Varnostni ventil f3 bar)	No.n'e'ed la adjUSI irii'al pressute of expai'slo' vessel	Ius igs riega in av . Mús reducü Iniiial pressure. Izračunajte ga bE'i sed ali üye.'sectILin "Cfe'W waler volurl e". Zagotovite, da je prostornina wa'er nižja odälowed' axlimumwslefvolufie(uslú9. Ihe figure belowj.	
	>7m	T nings potrebujajo lo oo . Musl li1cre'asê InitińT preßure. Izračunajte ga na podlagi oddelka "Količina kemične vode". Ens re wnter 'rolumo je nižji od dovoljenega največjega warer vnlHmo ttis'ng tho ^gt'ros below\	Ekspanzijska posoda je premajhna za namestitev. [Potrebuje ustrezno ekspanzijsko posodo ali tise saf+iriy ventil z úigh activolod presHre thal ir stipplied from local placu'

Krivulja največe količine vode Graf



- Pôoceś 'izračuna ällöweō največjega vraler volHme v wh'ole círculätion 's. Cšlcultat+ niáxlmun' voda voJuma sörrespölding to irítlat pressure Pg by usihg máximum water volume curvè aà sh-own b+low. C.onfrm lhø lolal največja prostornina valja v valju órculaLon je manjša od zgornje vrednosti. Oll1erwlše. Izpolnjevanje plovila v unll ià sm'aller za
Y*!8+'

N O T E

- 0.3 bar is the minimum initial pressure and 1.5 bar is the maximum initial pressure of expansion vessel set outside the factory.
- When initial pressure in expansion vessel is set as 0.3 bar at minimum, the water quantity required by system is higher than the limit value, it may be considered replacing expansion vessel with bigger volume.

9.3.2 Za vgradnjo in izpraznitev rezervoarja za dometske vode

(1) Polnjenje rezervoarja za toplo vodo

- Odprite vsako pipo za toplo vodo po vrsti, da se iz nje izloči zrak.
- sistemskie cevi,
- e L7pen \h# hladno par oskrbe ve,
- Po prečiščenju zraka elfov zaprite vsa vodna okanca.
- Preverite uhajanje valjev.
- Ročno upravljate Ifie Field-It zaustavljen tlačni odbojni ventil, da zagotovite pretok vode skozi' Ifie dialn plpe.

(2) Za izpraznitev vodovoda za toplo vodo za gospodinjstvo



#p â e ' 6th an MO de W ho

CAUTTO N

rojen RFP fna "acp*cif've ain'u" Create.

C:lose frie cmd watar'supply.


- Odstranite "gper fronr pan0T in she lownr front panel.
- Obešanje glavnega fiortti-oijlerja.
- Odstranite stop fr'm kte ianx.
- Uporabite drenažno hos'e a'td črpalko la draln lhe link yia ifie dralnage ouu l.
- Odprite vse zapiralke za vročo vodo, da lahko vstopi zrak. lhe system.

C AUT f ON

- Duri/ g T/ e use. of// e wa/ar fan'k, kera ma/ oo dll sedimen'fs eccumo/efed af r/ e boffam offl'e weter rem. in order /o avo'J the presence of dirty sediment affecting the heat exchange efficiency, resulting in increased energy consumption, it is necessary to carry out regular maintenance of the water tank.*



Ramov'e Ifie zgornjo sprednjo ploščo, glejte 7.3.1, nato pa ponovno namestite spodnjo sprednjo ploščo, kot sledi,

gtgg 1 Odvijte vijak
2 acrews



OGREVANJE/HLAJENJE PROSTOROV IN POMIVALNA VODA

S -p 5 Puah Th0 IrOr I peel fo ard.
"disange 'Ne."mep, konec nižji fom'p'anel je lahko



C AU T i DN

- Nekateri weter lahko fi'e .spilled the.n remoring /ie stoo finr fmlnegr outlet fm'm Ifie DHW.
- '4/- SYS rieen zr///eo' weTez.

PROSTOROV IN REGULACIJA DHW 0-

4 WATER

It is necessary to ensure the quality of water by decking pH, electrical conductivity, mineral content, sulphur content, and freezing point. Failing to do so may result in scale formation on heat exchanger surfaces. It is mandatory to ensure a high water quality with low levels of CaCO_3 .

Item	Chilled water system		Tendency (1)	
	Circulating water (20G)	Supply water	Corrosion	Deposits of scales
Water Quality pH (25 °C)	6.8 – 8.0	6.8 – 8.0	-	-
Electrical Conductivity (msm (38 °C) ($\mu\text{S}/\text{cm}$) (25 °C) ⁽²⁾)	Less than 400	Less than 300	*	*
Chlorine Ion (mg Cl ⁻ /L)	Less than 50	Less than 50	-	-
The amount of Acid consumption (pH 4.8) (mg CaCO_3/L)	Less than 50	Less than 50	*	-
(mg CaCO_3/L)	Leach 70	Loški Úan 70	-	-
Gallium flammable (frs ČeCÖJL)	Manj kot lahko 50	Manj kot 50	-	-
5 mm.L ² (mg Cu@L) (mg Cu/L)	Le preberi 1.0 lahko 0.1	Max. 1.0 Manj kot 0.1	*	-
Sulphur Ion (mg S ²⁻ /L) POSKUST P/L	Leach 0.1	Leach 0.1*	*	-
Remaining Chloride Ion (mg Cl ⁻ /L)	Less than 0.3	Less than 0.3	*	-
Hydrogen Sulfide Ion (mg SO ₂ /L)	Less than 1.0	Less than 1.0	-	-
Index of Stability	b.8 ~ b.0	-	-	-
Item	DRN space		Tendency (1)	
	Water supplied	Corrosion	Deposits of scales	-
Electrical Conductivity (mS/m) (25°C) ($\mu\text{S}/\text{cm}$) (25 °C) ⁽²⁾	1W-2@D0	-	-	-
Kloriné Ion ▶ mg Cl ⁻ /L)	Največ 250	-	-	-
Wiphate (mg/L)	Največja vrednost as0	-	-	-
Combination of chloride and sulphate (mg/L) (mg CaCO_3/L)	Mox 800	-	-	-
	't5D'	-	-	-

 NOTE

- (1) The mark "*" in the table means the factor concerned with

CAUTION

- Water should be subjected to filtration or to a softening treatment with chemicals before application as treated water.
- No antifreeze agent shall be added to the water circuit.
- To avoid deposits of scale on the heat exchangers surface it is mandatory to ensure a high water quality with low levels of CaCO_3 .
- To prevent the storage tank from corrosion, the electronic anode(optional accessory) can be installed.

9.5 DHW TANK SELECTION

NOTE

- DHW tank for heat pump type heating system shall be selected according to the requirements in this instruction and on-site use requirements.

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

If the selection, installation and wiring are not carried out according to the requirements in this instruction, we would not guarantee the correct operation of the DHW tank.

DHW tank selection (Storage capacity)
Hot water may cause serious burns. Test water temperature with hands. Use after the water is mixed in proper temperature.

Pri izbiro, namestitev in priključek na DHW sistem, take into consideration the following points:
Connecting of water pipe with tap water pipe should be

Prostornina rezervoarja mora ustrezati dnevniemu potrebujuščemu obsegu voda.

Če je voda mora alkalinat, naložiti rezervoar DHW wälér čljučilni stik za hidravilno hidravilno vodo (Ball).

Alkalini stik je mora biti nameščen na vodni izstop iz rezervoarja DHW tank. Ta mixinig valve shall assure that the hot water temperature at the hot water tap never rises above

the set maximum value. This maximum allowable hot water temperature is determined according to the applicable legislation.

Če je tlak na dnu starega predela MFC višji od projektnega tlaka opreme, je treba namestiti ustrezni tlačni razpršilec, da se zagotovi, da najvišji možni tlak NI

ažeče'ded.

Zmogljivost shranjevanja v banki za toplo vodo je odvisna od dnevnega povpraševanja po vodi in metode kombinacij. Dnevno povpraševanje po vodi je ocenjeno z naslednjo formulo za porabo:

$$D.(TQ = D/60 \text{ °C}) \times |60-T| / T-TQ$$

Kje:

- p; (T') Walar demerid al T I mparatu u
- Q; (60- C) Dornastic no\ kaj+r povpraševanje na 6d C
- T. Temperatura rezervoarja za toplo vodo
- T,- Tempara ru ali In iniat cotd wa\ar

- Calculation ali D, (60 °C):

KončMinacija sfandBrd, izražena v dalTy litrih na osebo in deiermlned s tehničnimi Installaions ofi eech Country, se uporablja za izračun gospodinjske potrebe po topli vodi pri 60 °C, D, (60 °C). Ta količina se nato pomnoži z izločenim številom uporabnikov te Installaition. V naslednjem prikazu je bilo upoštevano, da je potreba po gospodinjski toplozračni vodi BI 60 "fi 30 uporabnikov na osebo, pri čemer je 9 samostojnih hiš 68 s 4 prebivalci.

- Galutacija T;

temperatura TČ se nanaša na temperaturo nakopičenega vmetter v rezervoarju. pred D open bon. ta -mpefa\ure je običajno med 45 °C in 65 °C. To je bilo upoštevano 3? 45 °C v tem izvoru.

- Izračun Ti.

Temperatura dovodne hladne vode se nanaša na temperaturo vode, ki se dovaja v rezervoar. Ker je ta temperatura običajno med 10 °C in 15 °C, je bila v tem primeru upoštevana kot 12 °C.

- Example:

$$Di(T) = DO \times 4 \times t6O - 2 / 45 - Z = 474,5 \text{ litrov/dan}$$

$Z = 4.5 \times 2 \times 1 = 340 \text{ litters/dan}$ Približno povpraševanje po vodi

N O T E

f g /Ns mcmrnemkU rc m f@ fho ca/n/eed oonszm on hy W, w cese rher rhe inso/odbn ó rn e oeaWed fórse. 7 ur je dane za ensure a steady supply of hot water. In the case of a multifamily installation, it is not necessary to increase the forecast of hot water demand, given the lower simultaneity factor.

ELEKTRIČNE IN KRMILNE NASTAVITVE

FWsense

10. ELEKTRIČNE IN KRMILNE NASTAVITVE

10.1 GEHERAL CHECK

(1) Vse naprave, ki se uporabljajo na lokaciji (napajalniki, odklopnik, glav. oonduil in priključna plošča), so izbrane v skladu s tehničnim priročnikom ter nacionalnimi in lokalnimi predpisi. Ožičenje mora biti izvedeno v skladu z nacionalnimi in lokalnimi predpisi.

(2) Preverite napetost' ig withirt mtod vaTMge T9°. V Oase óf lów napetost. s étem III ni slart. Tn primerul visoke napetosti,

(8) Confiirn eárh wiry ie connectgd.

Uporabljaljate žice, ki niso "Tighfer thań fhe poly'chloro'prene sheathed flexible cord {code de6igngtion "6ÓZ45' TEC 57},

Modalni	Power supply	Opora@n Móde	*, cufren (A)	H'eweppi ca@es	I fansn nfing cabTes	CB (A)	ELB (No. of poles/A/mA)
(044.0GC/0S0) HCDB'2A-23	50+Tz	Wilh OHW eledric header	Z9.S6	5 x 6.0'mrrj*	2 x 0,7*5 mm	49	2/40/30

uB: A'c kroži okoli breakerja.

ELB: zemeljska pregrada.

c Au zio

- Turn OFF the main power switch of the indoor unit and the outdoor unit and wait for more than 10 minutes before electrical

NOTE

- Field wiring shall be in conformity to local laws and regulations, and all wiring operations must be performed by qualified professionals.
- Refer to relevant standards for Above-noted power supply cables size.
- Where power supply cable is connected through junction box in series, be sure to determine the total current and choose wires based on the table below. Selection according to EN 60335-1.

Curren i TA'	višina stez (mm*)
i s 6	2.5
s ' < i s 1f	2.5
10 s 1 s 16	2.?
16 * i s zs	4
32 < i ≤ 40	10
40 < i ≤ 63	16
63 < i	31

- As a minimum, the chosen wires shall not be lighter than the polychloroprene sheathed flexible cord (code designation 60245 IEC 57).
- The wiring specifications for weak current transmission circuit shall not be lower than that for RVV(S)P shielded wires or equivalent, and

- A switch that can ensure all-pole disconnection shall be installed between power supply and air conditioning unit in such a manner that the contact spacing shall not be less than 3 mm.

{7) 9wcef#egoicnb' demaged. fWdeaBrórfWgiBsq%g%fn>mde, gn'wfédmáiwfgharedwqedmecfm-%decowferf0dInn

- Za lle Ñsfe"/Et'en o Aower cerd, the. e-rtfi l-Yre r+ r?/ 0e fonper ihan lle.cirzenf-sarr'n'p condi/f /or


ELECTRICAL AND CONTROL SETTINGS

G

bo inner wiring and wi

w

e



Vse žice morajo biti trdno pritrjene s fiksiranjem
sponke in zagotovite, da je vsaka od njih debela.
reliably grounded.


Sponka za

The clamp for
wiring

Žice so trdno pritrjene s pritrdilnimi
sponkami in zagotavlja, da je končna žica
zanesljivo ozemljena.

ELEKTRIČNE IN KRMILNE NASTAVITVE


2. The wiring route outside electrical box, as below



10.3 PRIKLJUČKI NA PRIKLJUČNO PLOŠČO

10.3.1 Inéoor / zunanje tranemíšefon ožičenje

- prenos je priključen na priključka 1-2.
- Zaščitni sloj mora biti ozemljen.



- Za napeljavo iranskih emisij med zunanjim in notranjim enotom uporabite dve žici ($0,75 \text{ mm}^2$). Ožičenje mora biti iz 2-žilnih žic (Ne r+at uso žice z več kot 3 žilami).
- Uporabljajte zaščitene W res za Lronsmisson wrling in zaščiti The unite pred motnjami hrupa, wltf dolžina iess kot 300 m in velikost ln compltanca z lacanovimi kodami.
- Če ne uporabljate cevi za ožičenje na terenu, z lepilom premažite puše na plošči.

A KA UTI ON

Ensure that the transmission wiring is not wrongly connected to any live part that could damage the PCB

10.3.2 Temeljna plošča 1 (glavni napajalnik)

Glavna napajalna naprava je priključena na priključno ploščo (TB1) na naslednji način.

TB: Terminal board

• napajalni kabli


CB, CB: Odklopnik

Prenosni kabli

zračnega tokokroga

Q: Polje je dobavljeno, ni vsebovano v notranosti, razen v


ELB! Odklopnik proti tesnenju na zemljo




CAUTT ON

- Connect power line and earth wire to the harness.
- Check and ensure live line and null line of terminal boards in power supply are correctly connected. If connected incorrectly, earie pen' mey be oam's

Inputs and outputs printed on the board are the setting before shipment options. By means of the master other inputs and output functions can be configured and used.



28



Vnos - Sehing beTore shlpment

Mark	Igoscnptor	Ltefajžt sottir Jgs	Available input codes	Terminals	Specification
I1	Input 1	I - 08 (povpraševanje Oht/EliF F t y)	i - 00-17 (Except i - 07/12)	n.L oTB3	Closed/Open 220-240V - 50Hz
T2	Vnos 2	I - 13 (Cycle 1 and 2 ECO mode)	i - 00-17 (Except i - 07/12)	16, +12V on TB4	Closed/Open 12V DC
t3	npul3	I - 00 (No function)	i - 00-17 (Except i - 07/12)	I3, LB on TB3	Closed/Open 220-240V - 50Hz
I4	Input 4	I 04 (alar v	i - 0&17 (E "opi I - Ooh)	I4, L3 on TB3	Closed/Open 220-240V - 50Hz
I5	Input 5	I - uz (Gmrt Act.)	I h-1 (EscepT I - 07/12)	15, +12V na TB4	Closed/Open 12V DC
I6	Input 6	I - U6 (DHW B ost)	I - 00-17 (razen I - 07/12)	16, L3 oTB3	Closed/Open 220-240 V - 50 Hz
17	Vnos 7	I - 07 [Pnyyer meTer 1 ☒]	'00-17	I1, COM on TB#	Closed/Open 12V DC
I8	IB	I - 12 (Power meter 2)	i - 00-17	I8, COM on TB4	UIQ60dJUQ8'1 1 'Y DC
I9	Input 9	I - D9 (povpraševanje OM/OF F 2T	i.00-17 (Except i - 07/12)	I9, +12V na TB#	Zaprt/oprt 12C DC
110	Well 10	I - 00 (No function)	I - uu; (Except i - b1712)	I10, - IXV eln TB4	Closed/Open 1 DI
I11	Input 11	I - uu funkcija fNo]	I - 00-17 fExcept i - 07/121	I11, +12V na TB4	Closed/Open 12V DC

 **CAUTION**

Funkcije I - 0u"[Fowd Heeti oo//rigj /Funkcijaš I - 1D(fioree'd 6aatifp/Funolions i - TT{Forced čoa//ngj cannot be čsed at ploščice isti čas.

ELEKTRIKA IN KRMILJENJE GETTINGG

Hrsense

Input - All Input codes descriptions:

Vhodne kode	.Mank	Oaschnømn
- Dg	Brez premetitive I	
- 02	Smart Act./ :SG Odgovori Input 1	This function must be used to stop or limit the heat pump and Auxiliary electric heater when restricted by Electric company. It allows an external Smart switch device to switch off or reduce consumption of the heat pump and Auxiliary electric heater during time of peak electricity demand. In case of using Smart Grid application, this input is used as a digital input 1 and allows four different operating modes.:.
I - 03	Gwmmlng pôol Oamattd ON/OFF	Optional Input signal can be configured as function of "Swimming pool Demand ON/OFF" to operate SWP. Switch ON/OFF of SWP can also be controlled by master controller. Closed: Start SWP operation (Switch ON and Demand ON) Open: Stop SWP operation (Switch OFF and Demand OFF)
I - 04	Solar In	in casgi ol ain+r g Un I Cth solar pma, d' ls Input is used as a feedback for solar swim ržady. op.éiaion: Éiosad: Solár in'ON ce bugger s'oar pump operaööri, ON Open: Solar In OP-F to bigger solar pump ojaraüon USF
I - 05	FœooóH\$ainØCoblñg	Id C kvaPitev je mogoca changeo'byan npv!oian emœna! oonizm.egnal, HaaC ukorenjenje n6äö.bå.cnangâo overn åele eon%ceo GöséhdHœRng Odprto: ingmode
I - 06	OHWBcoq	wrs funkcija e?aoeo. je:p.ossiole \o zahteva rieäung up me:DNW wnen uporabnik oT OHW. Lr ggenng nput:algnat n območje Swch ON
I - 07	Power meter 1	\used as kW/n pup.count ter Ener§/. aara racaröing. usad .count anergy.Cats ce ih'eioe enetgy dätb.
I - 08	Demand ON/OFF 1	ÖgT Vhod 8 nan je mogocë konfigurati ña funktion gf "Oemanô ON/OFF 1" ali " iamanô ON/ÖFF 2" end selede'd gs ro'o. thereoe4el C16äed: n+om "ké'fzostat 5ÝtčL'ÖN in Thëmiö'ON. Open: ÖFF in Thermo OFF. óresjonding.rporfi iheñletlahko tudi Sciici+ O?/CiFF z Roöms fultl n na Mäsa@r'contrôljer.
- 10	FomedheaLng	r'wd neaCng dy "npu+oloon+oc1gBioKMeqCnBca", q ggemaqggoospy Cjo-u-d: Naçin FedHeating Odprto: Ne.acflon'
i - 11	Forced cooling	Forced Cooling mode by input or contact signal. Cooling can also be changed over by glavni krmilnik. Closid- F@æd Cool ng moda Open : No autløn
I - 12	Power meter 2	Vhod, ki se uporablja ko'hW/h število impulzov za Energy detg mooroing, u@ç lo rum energy ðæ ør totes onèrgy datzi.
I - 13	Oycie 1 in 2 ECO.rnoaø	Oyb 1 in cikel 2.Watar EOO oftæ'eL Clurrez1.yate' ýamparature. aMn'g ls raduced or Inæaaed "ý in0ic ieü perameier v rezervnem heellng mooe ali sgarë "l-ng móde. Gtoqed: Cyde l end Cycle 2 Water EGO offset.enabled Öpøn: yVatar EOO 'offset dlz oteö
I - 14	Cikel 1 ECÖ "moóë	Cyb 1 Water EOO , Julij najem wale Temperatura Ing lb reou èci ali v Neo øy Indicatød paramelar in apaea healing mafia or apaçø mlnig móóóé.... CI "es:.Cycle 1 Waer EcO atcabs Odprto: cikel 1 Waær ECO. offset + sebled
I - 15	Cycle 2 ECO mode	Cycle 2 Water ECO offset. Current water temperature setting is reduced or increased by the Indicatèò 'parentëtér in spece hëeting' ali epa'cç cðoing móde. Glosed- yc e 2' Waær'ECO offset omogoçeno ðoen: Üy@ 2 Weler ECO ólset onemogoçen
Id6	.For'eOFF	Forca OFF enota inçtida Voda Cyda l. Voda Cyde 2. DHW: rid,SWP. Swrtclj ON/ OKF ed dilfarent 1uncüón Bán alsö tip cõnkolM by rnøsTe'r copolar, Zaprt: DFF tfiè urit Tnck/de Woter Gybe 4. WSG Cyb 2..OHW.and WP' Open: No Clgn
i - f7.	BG Reaoy'nput'2	tncame.ofua+gó+nenGndapplimm n.m'a4npwlsawaaaaglæ inpu+zanoalnw tour.d%entog mlngmodm.

O ulpol - Sattng buf ra ehlpmorl

Mark	Opis [mon]	Defeurt oerting	Availa0e +zputut bez	fer m najg		Spaoficagon
01	Output 1	o - 01 (JWV '2WP)	o - óó - 3Ó (Excsp\ o - 02/Q8/17/2 T)		'ooT83	ONFQFF Zž0-240V - 50Hz Max. 1A
				Signalni zob	O1 on TB3	
02	Owpulz	o - 02 (WP3)	o - 00 - 30 (EXcegt o"17)	oTB2		On/OFF do-z4 0V - s0EJz Max. 1A
UL'	Oupuf3	o - 03 (Boiler combination)	o .00-30 (Izjema - 02/08/17/2 T)	.03 na TB2		Free voltage
O4	Output 4	o - Q4 (Solar out)	o-00- 30 1Lceplc-02D8 i7 wi	O4 on TB3		Free voltage
O5	Output 5	o - 17 (OHW Electric Heate')	o-00- 30	HL, HN na TB1		DN/OrF 220- 24ÓV- Ñ0Hz Največ. ¥5A.
.D8	'Oupul6	o - 1s (3WV DHW)	o - 0Ó - 30 loraz i7/2"		na TB3.	DN/OK 220-Z40V - Ñ0Hz Max. 4A
O7	Output 7	o - 19 (Mešanje vaTvo Close)	o - 00'- 30 (Mccp\ o' 02O8f17/2I}	07, N4 na TB2		
OB	Oupuv8	o - 20 fMixir+g yolve Open)	o-OD-30 l[xóeplo-OZ.O8f 7£T¥}	O8, N4 on TB2		@N/ FF 220-240 V - 50 Hz Max. 4A
od	oupu 9	o - 21 (WP2)	o.- 00 '-30 (Except o -17)	O9, N1 on TB2		ONWFF 220-240V ~ 50Hz Max. 1A
O10	Output 10	o - 22 (3WV Cooling)	o - 00-. 30 {Lyoplo-0£08. ñ2t }	Power supply	L1, Ns on TB3	DN/OFF 220-Z4 gV - ggHz Max. 1 A
011	Outp+Jt 11	o -.OD (WP1)	o - 00 - 30 (Except o -17)	Signal je v redu.	O1o on TB3	
Ó12	Ou well t2.	o-L (AC1)	o-DO-30 lExggp o-#Z 7Zt\$	012.W2 on ¥Bf		220-240 V - 50 Hz Max. zA
O13	Output 13	o -24 (Act2)	o - 00 - 30 (Except o - 02/08/17/21)	013, N3 on TB2		ÓWOFF O24f1V-5DHž Max. 1A
D14	OuPuT T4	o - 25 (Act3)	o - 00 - 30 {[xceglo -OZ68 i72t)}	014. N3. na TB2		ONOFF Jz0a40V-50Hz Max. 1A
015	Oupu 45	o-2B (Act4)	o - 00 - 30 (Exce@ o 02/0g*/17/2 T)	Ó15, W na TB2		ON/OFF 2A0V-S0Hz Max. 1A

Izhod -All..opisi izhodnih kod:

"u - 00	Ha Fuñcúon	
a - 01	3WV SWP	V primeru kombinacije Upit willi plavanje. pDol. ta augur se uporablja za driye. 3-wey vrednost preusmerjanje IO swJlt It IFig pool haqt exMangØr. Oklgçi OH 6al lahko 6Wtttttl/ng +owl fu:rlctlon ls
o - 02	WP3	V primeru, da je enota kombinirana z ločevalnikom, se uporablja u\ pulput la'drlve'telly ot'salar pump 3;
o - 03	"Narod kotlov	V casa o\ combln'ng enota wtfi aoliar. ms cutgur re.pseü to starvsØg \t.
o - 04	Solar out	v denarju po enoti s sončno energijo ai, rne ouTpuz je øged za pogon talay 6olar. Amp.
o - 05	Alarm signal	Ouput pečata, ko in Alarm Gooe occurs.
o - 06	SWP signal	.Ou put ON aignaT V primeru mat Swlmming pool kuncDn je.demann ON.
o - 07	Cooling signal	Izhodni podatki PM signai in cec" \hai Space cooiif+g je tfterwo-ON,
a "08	DELOVNI PAKET 1	In case of the pipeline connected to the unit is long leading to low water flow rate, this output is used to drive relay of an extra WP1 that can be cascaded with inside EC WP1 to offer additional hydraulic head. The extra WP1 works equally with inside EC WP1.
o - 09	Heating:alzg	'OuigurOn' signal v \fa cat Gpa a nealng je Tnarma-OH.
o - 10	DHW signal	Opvpt.ou s ai'- ra e 'hai ouw s <ema d na or.or.kiew< nealer a ou.
e - 11	Solar overheat	Output OH aignaT v paa, da so sončni kolektorji.overhead pro+ection's ætivateo.
9 - 12	Defrost	UuTpuz Ø s v primeru, da Tal je ouh¥ace enota a.ôafrasu!8-
a - 13	DHW purrs	Ouput'ON aignat io dr!a telay of à Ircula@ pump in ca'se of rø-çecü@on. p'umg ià avalle za C'HW taftk:
o - 14	NeaTar'falev 1	C gy.Oh/UF F sql ali Auxiløfy. eyre neøter'ouQuLTarm\nøl \t.
o - 15	Hojerij 2	Cagy OtwOF F sl ali Aux'l prizor t o be orpuz terrific a
o - 16	.o1 voda üN/Of-F	Ousnut OF signei v primeru mm water'GWe f swio IN.
o - 17	DnW Electnc Heater	Ourgut ON øpaT v primeru dna DnW E:lectrlc aaær's Enazife0 in več frs ÖN conolions.
o - 18	3WV DHW	In case of combining Unit with DHW, this output is used to drive 3-way valve diverting to the sanitary tank inner coil. Output ON signal when DHW function is operating.
a - 19	Mixing valve Close	Mixing valve has two operation terminals of closing valve and opening valve. Optional output signal need be configured as function of "Mixing valve Close" and "Mixing valve Open" to drive mixing valve.
o - 20	Mixing valve Open	
o - 21	WP2	Whin Waier Cycla 2 je na voljo Oğ#aaT Output ølgnat said ba œiføutea tó dtlve rday at' walè'r purhp 2.
o - 22	2WV Cö lIng	V kolenu ali combmp Unit.wrtfi óoolin'g'fen'cui. ihiš tgu\ se uporablja za'driye 3-wgy valve"t fin\ g' tó cooling fan cöil. Ötpui DN šignal when'sg'ace 'cool'ng is ö'gejätlng.
o - 23	dejanje1	soba acaJaøers. izhod Ô? signel v primeru:ße'ørresporiding F"eom nermosat:is Therrio .DN eaAnd cooTingi: Ko \h6 EDI fTg Ooaiio "s w.at, noom aktuatorji ate oao "t on: ① Air purge ② Anti-freezing ③ Mreød Drying
o - 25	Act3	@ tipka: delovanje zaradi preprečevanja zamrzovanja (&arrn-76 , d1-3 i. d1-03)
o - 26	4	's outürnt defrost wittlc-ur Rœm Thermostat Therrio. OF.
o - 27	'A'çIS	Öyerrun po reguir'ng .OFF
o - 28	Act6	Ko voda uycæ iB ava laolo Uqtonal ouqtonal s+gnp can.øe con igureol\ onve rely of excusiva water.pump'of Water Cycle.1.
o-50	WPc1	

Auxillary s-a-near - 9etting pred ehlpiem

Mark	Description	Default settings	Avalabfe aumhery senzorske oode
A1	Auxsensor 1	a - 01 (Tow3)	a - U0 - T4
A2	Auxsensor 2	a - 04 (Tow3)	
A3	Auxsensor 3	a - 02 (TewgJ)	a - 00 - t4
A4	Auxsensor 4	a - OS UowZ)	a - UU - 14
A5	Auxsensor 5	a - 14 (TDHW1)	a-w-*
A6	Auxsensor 6	a - 07 (Room_amb1)	a - UU - 14
A7	Auxsensor 7	a - 08 (Room_amb2)	a - UU - 14.


@xilwy kode senzorjev	MeE	OescnPtion
a - 00	za funkcijo	
a - 01	Tow3	This sensor is used in case to combine Unit with hydraulic separator to detect Hot water temperature detection of hydraulic separator.
a - 02	Tswp	\Cgse of comolInlg Unh wlm.swfmmplg pool, my. enpor I-§.usea to detect swlmming pool water temperature.
a - 03	Car	lncqgeocomlngUnlrwin. fmpanes, i: q+mmed io.Demm'9olwyn mnpwraw ofBola'pen06'.
a - Q4	Ta_a0	Opho el 9.econd @uTdaor Ambient Temperature sa?sor acceaagry can be nu@d O pa ATI#ary san'aor In ca'e" tla' the haet p-m'p Is I<<AM In iz non-azJitable.po6ilio'n fat zhls rrieesureme'nt.
a - 05	Tow2	When Water Cycle 2 is available, auxiliary sensor need be configured as function of "Tow2 IN:defect'oule'lwater te'mpe'reliJre offWa r GyEfe 2.
a - 06	služba	Used to detect duty signal when duty signal control is Enabled; the duty signal type can be 0-10V, 0-5V or 10-20mA.
a - 07	Rosm_amo1	
a - 08	Soba amDz.	
a - 09	Room_amb3	
a - 10	Soba amb4	
a - 11	qpmp pmp\$	
q - 12	Room_amb6	
a - 13	Room_amb7	
e - 14	TDI WI	T m- senzor TDnWIs auxiliary eensor:'o deiect tank. voda. \Pomočni senzor moči e 'e.

D A N G E R

- **Do not connect or adjust any wiring or connections unless the main power switch is OFF.**
- **When using more than one power source, check and ensure that all of them are turned OFF before operating the indoor unit.**
- **Avoid wiring installation in contact with the refrigerant pipes, water pipes, edges of plates and electrical components inside the unit to prevent damage, which may cause electric shock or short circuit.**

C A U T I O N

- After changing the input settings, output settings and auxiliary sensor settings on the master controller, it needs to be powered off and on again to take effect.
- Use a dedicated power circuit for the indoor unit. Do not use a power circuit shared with the outdoor unit or any other.
- Make sure that all wiring and protection devices are properly selected, connected, identified and fixed to the corresponding terminals of the unit, specially the protection (earth) and power wiring, taking into account the applicable national and local regulations. Establish proper earthing. Incomplete earthing may cause electric shock.
- Protect the indoor unit against the entry of small animals (like rodents) which could damage the drain pipe and any internal wire or any other electrical part, leading to electric shock or
- Keep a distance between each wiring terminal and attach insulation tape or sleeve as shown in the figure.



ELEKTRIČNE IN KRMILNE NASTAVITVE

FHsense

10.5 NASTAVITEV STIKAL DLP NA PLOŠČICI PCB1


NOTE

- The mark "■" indicates the dip switches positions.
- No mark "■" indicates pin position is not affected.
- The figures show the settings before shipment or after
- "Not used" means that the pin must not be changed. A

CAU T10 N

Before setting dip switches, first turn the power supply OFF and then set the position of dip switches. If the switches are set without fmn/n rhe got suq,q/y OF-F. frio.ovlšnts N ffie sun/ng e/e ir+ye//d.

(1) DSW1: Union model 'setting
No seOrt'g Is required.



(2) DSW2: .Unie capa i ty .settIrtg
Nó setTirtg Is requIre'd.

2 0 nP)	0b0t2 5 HP}	08043,0 H Pj

(3) DSW3: Dodatek'at seltin'g

Sattln'g boflóra sh pmeńska	
ÓN ! C*anoul 70 vetru Wattir preqsW abriom-akfy	
AotI-freezJng setTfnngs ÓN: Wn'ofe voda f-yóu *douia an\i-freuzIñ+g. OFF. Orily primar y cycla dws en\i-f+aeyi+g.	

(4) DSW4: Dodatni selting

Postavitev pred sllifimentom	
W%tozpumpkvopDON	
Pomožni elecbiš nealer fórcod ÓFF	
Of4: Anti-freezing enabled OFF: Anti-fn-ezinQ .disabled	

Voda P mp mede ko Ttierrá'i' OFF oN: na "a> yas<aie OFF: Opeain OrnsJly	
ON!hlant ii em'ergencr entatled OFr: td%tual e*riturtjuwy OlsabJuu	
DHW electric heater allowance setting ON: DHW electric heater cancel forced OFF OFF: DHW electric heater forced OFF	
DHW 3-way valve forced ON	
Start air purge	

t0j ua's ddnronai se ung

Sehln'g pred odpremo	
OH: Gan@ 75/T8 ierrn fWater pump abormalDjes	
ON: WP8 oPerslea. in spuce roolir'g.mode	
VKLOPLJENO! Ead cet Atann ali Tnenntab r.Tow2	

(6) DSW6: Fuse reset


--	--

(7) DSW7: Additional setting

Nastavitev bolöre shtpmment	
ÓN: Prekličite alarm ÔhermIstor Tow3	


(8) DSW8: Refrlger sistem št. senln9
Setting is required.

Uporabite binarno metodo eícočing, Bsforg šip'rment are'
all OF F.



Ma X No,63 are avsifa6tg to'set ahe n aTl the equipment are
co'nected to c.orresgonding Contra | Con trol Eystem.

Emu Tt hladilni sistem št. as 8.



(9) oSW9: V enoti vrat št. setting.
No setting is required.

Nastavitev before.shipment	
----------------------------	--

11. TESTNI PREGON

* NOTE

NEVER operate the unit without careful inspection.

11.1 KONTROLNI SEZNAM PRED TESTIRANJEM RUŃ

D.a NOT opér@ei thø šystgm pred ß'e fõilowling DfiaÖtå ØÁ.

OK:

nava reoet the compete instaTlation InetručzDrt of ouluoor enota, 'roof unl in maszar contraflar careAJity,	<input type="checkbox"/>
The indoor unit is properly mounted.	<input type="checkbox"/>
Zunanja enota je propadla.	<input type="checkbox"/>
Th".ol wińg unit.wiring free seen. cōmed out roe rdng tō did doc merit:gnd ma. äpplicäblo legèlaôort:	<input type="checkbox"/>
<ul style="list-style-type: none"> • BaMa āa th'a.løcøl paver upgly in. th outdaør onto - Bender'in unt in zunanja enota • BeMean tha.ll po'n supply anü tlle:indoor unl - Between the indoor unit and the valves (if applicable) - Ben 'lie moor uni end the'. oom tñermosta' if applicable) • Stava shahdl unl in the OHW Leith {Če se uporabla 	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input checked="" type="checkbox"/> <input type="checkbox"/>
Fueée. lokalno -nSLalM gró ećooe dqviceē'aro InstaTlaç aocording to iñ*a:docum*ent: ei'l'd nan NOT.ba��n d'ypa'saad:	<input type="checkbox"/>
Tta��l peter ø ppty vohaga rna cf+ss the vol ago on tha Nam��pW iz unl.	<input type="checkbox"/>
Thare so TO Tooae.comma or.'damegeo elektrike! p��r je v zgodbi 8/lawTC81 Rok.	<input type="checkbox"/>
Tñere a're NO damaged compone ta ør aguald #ipa��rin it��sTae i ana outoCer enote.	<input type="checkbox"/>
Samo za Di-lW.tqnb z eleclric tieot��r.	<input type="checkbox"/>
Imporsrgfure.pr9trciuen cwilih Auto rauter)Lia��hga'n Temperatura ptot�� "zBon s4toh Temperetura fuse.haa b��rn g��lready /vii^ed.	<input type="checkbox"/>
Tm "aceNO 'nmugmac "	<input type="checkbox"/>
Watar pipes e're tli��+inelfy vdihavajo.	<input checked="" type="checkbox"/>
uid)	<input type="checkbox"/>
Tho Cofree p stzo ali c��rlgawt plpea tgas attd 'lfz So,ne arid tateve ere imperitl nsplited.	<input type="checkbox"/>
ahul-olf yehree kot. pravilno insielW in popolnoma odprt.	<input type="checkbox"/>
Tfi�� øt��g vah/ea {gaa hand lf+d) on The.ou d��gs unlT ara kg'	<input type="checkbox"/>
The air purge valve is open.	<input type="checkbox"/>
Ko se odpre, se iz��sti w��ter.	<input type="checkbox"/>
m��lntrnm m æt��r vaJuma s.guaran��e��d ln.��lt. cond/Aris See "Ch��ck weter volfirn'e" urKfer*Üction 9.d "W��ter I "T��ing"	<input type="checkbox"/>
Th�� DHW Ok. is filte�� CDITfp'lately.	<input type="checkbox"/>

CAUTION

- The unit starts only when all check points are cleared up;
- Pay attention when system is running:

discharge temperature of compressor can be more than

90°C.

(B) Do not press AC contactor button, otherwise serious accident may be caused.

- Do not touch any electrical components in 10 minutes after main power supply is cut off.

11.2 KONTROLNI SEZNAM MED IZVAJANJEM TE9T

Iris minlmam Box raw du+mg eMnc neater/defrosr operaan ie guarwead i-n all on-n'öhons. Gaa oddelek "B.2 beEurerneftts.anl re m'en'dBtione f'i'r hyôraultc 'ci'cuit' and 'R:5 Wstér filling'.	<input type="checkbox"/>
za Psrlø'n an 'str piirø'g.	<input type="checkbox"/>
Izvedba a.tøøøt teka.	<input type="checkbox"/>
To p��rforwr an aktuic'r to'at run.	<input type="checkbox"/>
underfloor screed drying function The underfloor screed drying function is started.	<input type="checkbox"/>

CAUTION

- When performing test run of floor heating, higher temperature in indoor unit (up to 55 °C) will damage floors due to expansion and contraction. Recommend it is within 30 minutes.
- Use the controller to start test run (refer to the manual of master controller).
- It is normal that after indoor unit is energized, it may directly enter anti-freezing running mode, and water pump automatically runs if outdoor temperature is very low.

11.3 PREVERJANJE NAJMANUŠEGA PRETOKA

1 Ch+ck the riulic .config "reilon.u find.out Fch space'f+eeöng l��wp's c��n ôtose'd by merži'nic'��l, e@tron��. or other' ��lvea.	<input type="checkbox"/>
2 Zapri vse rla��irig IODps mat Ean be. etased.	<input type="checkbox"/>
3 Zagon testnega zagona pcirng . Oglejte si nastavitev D5W4-80 razdelek "10.6 D/R GwIM:5eUng.of PCB1".	<input type="checkbox"/>
4 Read out the flow rate and modify the bypass valve setting to reach the minimum required flow rate + 2LYmln.	<input type="checkbox"/>

TEHNIČNI PARAMETRI

12. TEHNIČNI PARAMETRI

Hrsense

Tehnični parametri

nutaoor uniL	AH	HID	n	#H	À4HCDÜAA-23
Oukoór stran heàl exohatigür 9f sìr'oo'ndllioner'fw t cir/mp. gh"					
Indoor.siða. hëat exchanger or sir conditioner/heàl pump: weter					
Type: cómprws'or ôfiyen'vaóúr oomss)on					
ÔrtVgr ali kompresor: aWtúc motor					
IndcaTlön Če da taaiaaiài equeppeô s suúulan antat.y Caatéi -yaà					
Paravel++rs shajl aa daOarod.Sr lhe auge heatjr-g saasoi					
1téffí'	ISS5	bD	V@	Un	.unit

Paršfn ten sh%TI be "deUerad fori				Lnw ūtemperetuie' %plion			
Rated heating capacity	R "	4.44	kW.	Seasonal space heating energetska efifiiency.	Q _{he}	197	%
Oecafe.d ogrevalna zmogljivost.za. *£'g';d oufdpor lamperaw'ro.T	pärt obremenite v gt	'n z u-mp zaželeno je, da bi se kW	Dclared.ooeffi t;04 opravi l 'mpełatute'2Q °C'S'rió ouzdo Tj = -7°C	anceFAverage seaapp t wmp'Brów T]	COPd	3.29	—
Tj = -7°C	Pdn	2.4	kW	Tj = 2°C	COPd	4.80	—
Tj = 2°C	Pdh						
Tj = 7°C	Pdh	1.7	kW	Tj = 7°C	COPd	6.44	—
Tj - 12 °C:	f?dh	2.2	kW	• T2 °C	COPd	9.02	-
Tj = arvalont lempetaMre	I?dh	2.9	kW	T/- alval nt tar" eraiu	cOPo	3a9	-
Tj = operating limit	Pdh	4.3	kW	Z = operabrlq limil	COPd	2.63	
8 valon iamperature				Oporat'ng rmzt.te raturg			
heRing/AverRge	Tbiy	-7	"C	heating/Average	Tol	-10	"C
heating/Warmer	Tóiu		"C	naatng/Warmgr	Tol		"C
'iestaincl/Col pred'	Tbiv	-	"C	ogrevanje/.AT0er'	col	—	
Oagradáón co-effióent	Ce	0.9					

Offin:Of	P _{off}	0.040	kW	Standipripravjenosti.	P58	0.010	kW
Thermostat-off mode(heating)	P _{tc}	0.011	kW	Čiancase heater mode	PCK	0.001	kW

Supplementary capacity	P _{sup}	0.102	kW	Type of energy input	Electric
Other items					

Capacity control		Variable		Air flow rate, outdoor		2700	m³/h
Reference annual heating demand	Q _{ref}	\$88919	\$/kWh	'Stund power level', Indoor/ outdoor measured	LWA	42/61	dB(A)
Annual energy consumption	Q _{he}	1824	kWh	Global warming potential	GWP	675	kgCO ₂ eq.

Contact details	Qingdao Hisense Hitachi Air-conditioning Systems Co., Ltd No. 218, Qianwangang Road, Economic and Technological Development Zone, Qingdao, China
-----------------	---

Tehnični parametri

Ch iron nnl -

|j 4l-jC

AI-! S'4äêî-fGDSAA-23

Outdoor side heat exchanger of air conditioner/heating pump: water

Type- T_{c} omp'm'ssor d+iven vapour compression

Origin Of CDmpf e6sqi : chet fin r t v10f

ndicafiu i če v a ff ff i-é equippea wīh a supplemeütary' fi46wr: ye

Parameters shall be declared for the average heating season.

Tehnični parametri

w Dc

cD 2

O'u1dóór' Tdó toplota eixchdtl-qa=z al.'gir @n'dióoner/hot pomó:

air' Indoor slda h'eat axcfianger of air corditioner/heAT pump:

water Ty#e: cómp'Fc'ss'or driven vapóur compresašioń

Orivar ali compf ssqf:jMfic nsqfot

Indteatlof.If na.h'eater is'e9-ipped witti a'suppl eñtary heatar..y 's

Peremete.rs.sfl\ell bo deciered £or 1fie moge.heating saæecn

1	yríb Va1	n	T	S	enota
---	----------	---	---	---	-------

Pemmetarś sKa1l iba deótarad forr				LDw	peratu ap'pl	tion"	
Indpor ttoal excha				Variable outlet			
Haład Taating capaeity	R,..",	8:T0	kW	Seasongf Spare'heating energy efficiency	r _{b,a}	194	%
Oactafed heating capaofy za 20°0 in "outa>ai wm'pgrawr	pan charge ar e T _j	Notranji īemp	arat	Qeclareo coeffiÓent al.parfotm TamperaMre fió "G a'nd ouTdo	ancafAy rance paratu	sezona ge ra T	v zaprtih prostorih
Tj = - XC	Pdh	5.4	kW	Tj = - 7°C	ÜOPd	3. 3	
Tj - 2°C	Pdh	3.S.	hW	T _j = 2°C	COP-s	4.67	-
TI - zC	P0h	fl.LI	kW	7j'-7 °C	COP4	'B:68	
Tj.= 12 C	Pdh	2.2	kW	fj = T2°C	COPd	9.92	-
Tj:= o aie i iemperaxirs	Pdn	e.+	kw	T _j = aiv.aleni le iure	Gooo	3. 3	-
Tj.= óperating lII	Pdh	5.3	kW	T/ = operatirtg.tlimit	CÖPö	'2.66	-
BivaW.ta Yjpera är e				Operating limit t+jaiure			
healG/Avätage	Tbifi	-7-	"C	hing/A bes	TG	10	'G
nsa armar	Tblv	-	"C	n atlng/warmor	Tol	—	°C
fial'g/Golder	Tbi?	-	"C	heeting'CoTder'	Tol	—	°C
OogradaW ca-afflÖant	Cd.	0:u.					

PoiConoom'p#onin''medesolithan.''like'moói

Off mode:	P _{OFF}	0.010	kW	Standby mode	P _{SB}	0.010	.kW
Thermostat-off mode(lessAng)	P _{so}	0.011	kW	Crankcase heater mode	P _{so}	0.001	.kW

Supplementary heater

Supplementary capacity	P _{sup}	0.729	kW	Type of energy input	Electric		
------------------------	------------------	-------	----	----------------------	----------	--	--

Capacity control		Variable		Ait flow raj, outdoor		2700	m ³ /h
Reference annual heating demand	Q _H	12507	kWh	Sound power level , indoor/outdoor measured	LWA	42.62	dB(A)
Annual aerogy colsumption	Q _{HE}	2539	kWh	Glob-H warming potential	GWP	&75	k9CO ₂ eq. enak.

Contact details
Ctingdan H'sana 'iiiam rur-condtMnIng'.8ysterna Oo., Ucl
Št. z1B. Oianwangenq.Road. Economi an0 Technological 0.Ryslogmen Zone,'D!ngdao, .Chlna.

Tehnični parametri

"Outdaor unlüH	HCD	OEC ōSWf13 ŒtdWr stranska toplosta e* har+her r'f str		
oondl\loner/topilna črpalka:alr				
Notranja stranska peta exfonger n̄f sir	rMtipnēr/fiea črpalka:	watèr		
Vrsta: kompresor dfiyen parna cempresija Oriver of				
c'ompra'ecoreWñç rñtotot				
IndWron Če se haälør re qqulppoo z g s pplamøntary haatør. yoo:				
Pärante en àhøll oa' dectare'd Tar die'a'	ge' heating aaaão lo			
Item	S b	Va4 e ii	al	enota

Pererneters shell be deOere'd for				Srednja temperatura appfice			
1ndciör ziea'a hanqer:				varlaüg ouäet			
Rated heating capacity	P _{max,heating}	5.37	kW	Séaaönel spece heejng enegyèR'emcy	P _{max}	130	%
Oecifisfèd hèatfig.capeófy' za' 20 "E in ven tempáraMr	part.loa0:et e'Tj	třby tě'mg	e' tukaj	Deklarirani koeficient izvedbe 20 *C. and out'úoo	ance'/Ay'er r.namperal're Tj	ge seeon v zaprtih prostorih	
Tj=-7 °C	Pdn	4.7	kW	Tj=-.7 °C	CoPd.	s.a.	-
Tj=2 °C	Pdh	3.0'	hW	V.=.2 °C	COPd	3.2t	-
Tj=7 °C	.Pan	2.0	'kW	Í -7 °C	COPcl	4:34	-
Tj*12 °C	Pöh	2.0'	kW	Vy-12 °C	COPd	7.24	-
Tj=aivølantlon'peraMre	Pan	4.7	kW	L = awalent ternparatuta'	COPa	2.D4	-
Tj- oserei:nglmii	edh	4.s'	kW	ri= nereii "gilmii	CoPd	' z	-
B valen' ie'mperäture				Oparaang.irrn I rerrøaratura			
ogrevanje/As.age.	Tbiv	•7	",G	ogrevanje/Avereg-e	Tol	-10	*G
naa#n'g/Wárñiaj	Tblv	-	"C	neating/Watmer	Ta	—	°C
zamrznitev/pomnilnik	Tbiy	-	"C	ogrevanje/C6der	Tal	—	°C
õagradaïto čo-affiÖent	Cd.	0.9					

Polar conaumpÜm in modes other lhen 'eclve me'

Off mode	Stran	0.010	kW	Nastidby mode	Stran	0.0.fo	kW
Thermostat-off mode(heating)	P _{off}	0.011	kW	Craniöase healer mode	P _{off}	0.001	kW

Dopolnilni grelnik

Gup Pm1azy cap'ačJzy	0 06	W	Electric
----------------------	------	---	----------

Capacity control		Variable		Zračni pretek satdoor		2700	m³/h
Reference annual heating demand	Q _H	11032	kWh	zunanji Sound power level , indoor/ fauna power level . out óbr meäsure +1	LWA	42/62	dB(A)
Annual energy consumption	Q _H	3312	kWh	Global warming potential	GWP	675	kgCO ₂ eq.
Comptc .details	Oln'gdä'o Hisense FTI+a'člň År-có'ndifiorńg 8yätems'Co.. Llö. No. 218, Qianwangang Road, Gospodarsko in tehnološko območje Dë'velöpmenT." Oirødao, Kitajsko						

Tehnični parametri

'üuldó'y uolD

HAQHW

AHA-@B0HC

28.

Notranji èiôe: h'e'øt 'ex fiange'r of @r cpñrfitipner/hee pump:

w8tèr Type: compraesor dren vapoúr comorøssíDD

Inō@tlon if be haëter is.ogulpood Ash a suoplamønTary fifeater. yeo

Pz amelørä'shall oa' prijaylieno za ploščico aAge hëatir\q saasOn

Artikel: bD Unija enota

E*ærerneters shall òe deoered. for toplota za ogrevanje				Epolacija tønperature L ow tønperature heraget: @FIBDIØ DHABI			
Rated heating capacity	P _{max,th}	6.50	kW.	8åá ñmeheewng energÿeiañcy	T _{b,th}	184	%
0.č'ÁBrèd.heating cäpeóry z 20°C in outdoor seríperaMr%	part.loed.at T _j	iń s teñip	erafvre	Decläred.'köeffiöreńt öf pë'rwt \ß.-G end outdoo	riönce/Avér r'tamperat	ge see'són re T _j '	st irido'oí
T _j = -7°C	Pdh	5.8	kW	T _j = -7°C	COPd	3.14	—
T _j = 2°C	Pdh	3.5	kW	T _j = 2°C	COPd	4.84	—
T _j = 7°C	Pdh	2.3	kW	T _j = 7°C	COPd	5.98	—
T _j = 12°C	Pdh	2.0	kW	T _j = 12°C	COPd	9.67	—
T _j = bivalent temperature	Pdh	5.8	kW	T _j = bivalent temperature	COPd	3.14	—
T _j = operating limit	Pdh	6.2	kW	T _j = operating limit	COPd	2.66	—
&va 'ærnþärtature				Oparating l mil tempoeazura			
heagztg/Averqge	tbiv	-7	"C	heaticg/povprečno	Tol	-10	"C
naä fig/Wa'rmar	TDlv	-	"C	haatińg/Warmgr	Tol		"C
neaMQColder	Tbiv	-	*C	ogrevanje/0.oldier	Za1	—	"C
Ôagrada@ cci-affiÔent	Cd.	0.9					

Poi. r.'cønwmc v načinu nNi potem 'øtTyve m'orie'

Off mode	P _{OFF}	0.010	kW	Standby mode	P _{SB}	0.010	kW
Thermostat-off mode(heating)	P _{TO} an	0.011	kW	Cranfixøse:heeler/møde	P _{CK}	0.001	kW

Supplementary heater

Supplementary capacity	P _{sup}	0.343	kW	Type of energy input	Electric
Drugi obiectivi					

Capacity control		Vanatje		Zarabij pretek catalog		2700	m³/h
Reference annual heating demand	Q _H	13441 441	kWth	Sound power level, indoor/ outdoor measured	LWA	42/64	dB(A)
Annual energy consumption	Q _{HE}	2732	kWh	Global warming potential	GWP	675	kgCO ₂ eq.

'Conpn.debiU Qingdao Hisense Hitachi Air-conditioning Systems Co., Ltd
No. 218, Qianwangang Road, Economic and Technological Development Zone, Qingdao, China

Tehnični parametri

Ouldaor uniL

UL

CD

ARE-O80HCDSAA-23'

Indoor slde neet eycnanger el air co "ü'fioner/neai eump. wa'er

Yype- comprwor a+iyen vØpO -r cornpžen*o'n

Oriyar ali comprécor:qW ric motor

Indication if be hêat 'r ia egulpped with a supplementary heater. yes Parameters

Shell la dac4qrad.for ma average heahng seaeon

ups	s	b		u
Heating				
Parametri lupine se deUere'd za;			Medium teksture apprallon	
Notranji izmenjevalnik glave.			Spremenljivka outlet	
Rafeg hea t'ng zmogljivosti.	P "	5.90	hW	Sgamonel space heeling eneyebenj
Deed denting mp��c ty firs 20 "G in ou�� em'peraM	delna obremenite v a. e T]	notranji te.mp	eret re	Izjava coej'lir@1 ali:perfo tempera% 20 "C an�� outd��o
Tj=-7 "��	Pdh	5.2	kW	V��=-7 "C
Tj=2 "c	Pdh	3.2	hW	f��=2 "C
Tj=72 "C	Pdh	2.1	hW	Tj=7 "C
Tj = bivalent temperature	Pdh	5.2	kW	Tj-iZ "C
Tj = operating limit	Pdh	5.7	kw	V=bivarianttemparatura
			kW	7j = meja oppralirig
B@lent cemperat��re		-7	"C	Operating ltm* tempara tura
zoeTl/Yq/Av��r-age	Tbiv			Ta
klesan marmor	Tbiv	-	"I	ogrevanje/Wa rrner
noarn/Coldar	TbIy	-	"C	naatIng/Calder
Oegreda��a+i co eff��ient	Gd	0.9		
Str	0.010	kW	Pripravljenost v stanju	
Off mode	P _{off}	0.010	kW	Strapavljeno m��o��e
na��in	Stran	0.011	kW	P _{se}
Thermostat-off mode(heating)	P _{to}	0.011	kW	Na��in ogrevanja karterja Crankcase heater mode
				P _{tc}
				0.001
				sorodni kW
grelnik 6uppie				
8uppW andTary capa��ty	KdoP	0.79	p t	El��ctrte

Olhelems

Gas/Chemical		Variable		Sound Power level, outdoor		2700	m ³ /h
Reference annual heating demand	Q _H	12081	kWh	Sound power level, indoor/outdoor measured	LWA	42/64	dB(A)
Annual energy consumption	Q _{HE}	5536	kWh	Global warming potential	GWP	675	kgCO ₂ eq. npr.
Contact details	Qingdao Hisenae Hi��efii Ar-conditioning Systems Co., Ltd. st. 21g, Qianw'at gang Road. Eorlo "lo aths Tect'nologl<al Ue elogr\ ant Zo+\e. Chngdao, Cfl' a						